

HYOSUNG

MODBUS Slave

MODBUS Serial Slave Driver

Supported version

TOP Design Studio

V1.0 or higher



CONTENTS

We would like to thank our customers for using M2I's "Touch Operation Panel (M2I TOP) Series". Read this manual and familiarize yourself with the connection method and procedures of the "TOP and external device".

1. System configuration [Page 2](#)

Describes the devices required for connection, the setting of each device, cables, and configurable systems.

2. External device selection [Page 3](#)

Select a TOP model and an external device.

3. TOP communication setting [Page 4](#)

Describes how to set the TOP communication.

4. External device setting [Page 11](#)

Describes how to set up communication for external devices.

5. Cable table [Page 12](#)

Describes the cable specifications required for connection.

6. Supported addresses [Page 14](#)

Refer to this section to check the addresses which can communicate with an external device.

1. System configuration

This driver is the "Serial Slave Driver" among the "MODBUS Protocol" of "HYOSUNG".

Depending on the external device (MODBUS Slave Protocol supported), you may set the "command code", "protocol frame format" etc., of the driver separately. In this case, set the detailed settings according to the external device side based on the communication method.

The system configuration with an external device supported by this driver is as follows:

Series	CPU	Link I/F	Communication method	System setting	Cable
HYOSUNG MODBUS Slave Device			RS-232C	3. TOP communication setting 4. External device setting	5. Cable table
			RS-422 (4 wire)		
			RS-485 (2 wire)		

■ Connectable configuration


- 1:1 connection (one MASTER and one TOP) connection



- 1:N connection (one MASTER and multiple TOPs) connection




- 1 : N connection (multiple Masters and 1 TOP) connection



2. External device selection

- Select a TOP model and a port, and then select an external device.



Settings		Contents									
TOP	Model	Check the TOP display and process to select the touch model.									
External device	Vendor	Select the vendor of the external device to be connected to TOP. Select "HYOSUNG".									
	PLC	Select an external device to connect to TOP. <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="background-color: black; color: white;">Model</th> <th style="background-color: black; color: white;">Interface</th> <th style="background-color: black; color: white;">Protocol</th> </tr> </thead> <tbody> <tr> <td>HYOSUNG MODBUS Slave</td> <td>Serial</td> <td>Set Users</td> </tr> </tbody> </table> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="background-color: #e1eef6;">Supported Protocol</th> </tr> </thead> <tbody> <tr> <td>MODBUS RTU</td> <td>MODBUS ASCII</td> </tr> </tbody> </table> Please check the system configuration in Chapter 1 to see if the external device you want to connect is a model whose system can be configured.	Model	Interface	Protocol	HYOSUNG MODBUS Slave	Serial	Set Users	Supported Protocol		MODBUS RTU
Model	Interface	Protocol									
HYOSUNG MODBUS Slave	Serial	Set Users									
Supported Protocol											
MODBUS RTU	MODBUS ASCII										

3. TOP communication setting



The communication can be set in TOP Design Studio or TOP main menu. The communication should be set in the same way as that of the external device.

3.1 Communication setting in TOP Design Studio

(1) Communication interface setting

■ [Project > Project property > TOP Settings] → [Project Options > "HMI Setting Use" Check > Edit > Serial]

– Set the TOP communication interface in TOP Design Studio.




Items	TOP	External device	Remarks
Signal Level (port)	RS-232C RS-422/485	RS-232C RS-422/485	
Baud Rate	38400		
Data Bit	8		
Stop Bit	1		
Parity Bit	None.		

* The above settings are examples recommended by the company.

Items	Description
Signal Level	Select the serial communication method between the TOP and an external device.
Baud Rate	Select the serial communication speed between the TOP and an external device.
Data Bit	Select the serial communication data bit between the TOP and an external device.
Stop Bit	Select the serial communication stop bit between the TOP and an external device.
Parity Bit	Select the serial communication parity bit check method between the TOP and an external device.


(2) Communication option setting

- [Project > Project property > PLC setting > COM > "PLC1 : MODBUS Slave"]
 - Set the options of the MODBUS Serial Slave driver in TOP Design Studio.



Items	Settings	Remarks
Interface	Select "Serial".	Refer to "2. External device selection".
Protocol	Select the communication protocol between the TOP and an external device.	
TimeOut (ms)	Set the time for the TOP to wait for a response from an external device.	
SendWait (ms)	Set the waiting time between TOP's receiving a response from an external device and sending the next command request.	
Station Num	Set the TOP (Slave) prefix.	
AccessMemoryRange		
0 Devie	0 Device ADDRESS Range Setting	
1 Devie	1 Device ADDRESS Range Setting	
3 Devie	3 Device ADDRESS Range Setting	
4 Devie	4 Device ADDRESS Range Setting	
PacketCountSystemBuffer		
ReadPacketCount	ReadPacket Count	
WritePacketCount	WritPacket Count	
[32BIT SWAP]	Not used, used	

[32BIT SWAP] Changing Unuse to Use will activate the options below.



- 32 BIT SWAP MODE
 - Big Endian Format(4 3 2 1)
 - Big Endian With byte-swapped(3 4 1 2)
 - Little Endian Format(1 2 3 4)
 - Little Endian With byte-swapped(2 1 4 3)

Put the 4 forms of data on the master and the default value is Little Endian With byte-swapped (2 1 4 3).
- SwapAddressRange


The swap sytembuffer range. If you don't intend to use it use 1 to 0
- SwapAddressCount

You can choose individually, and not scope. Choose from 1-9.

3.2. Communication setting in TOP


* This is a setting method when "Use HMI Setup" in the setting items in "3.1 TOP Design Studio" is not checked.

- Touch the top of the TOP screen and drag it down. Touch "EXIT" in the pop-up window to go to the main screen.



(1) Communication interface setting

- [Main Sree > Control Panel> Serial]




Items	TOP	External device	Remarks
Signal Level (port)	RS-232C RS-422/485	RS-232C RS-422/485	
Baud Rate	38400		
Data Bit	8		
Stop Bit	1		
Parity Bit	None.		

* The above settings are setting examples recommended by the company.

Items	Description
Signal Level	Select the serial communication method between the TOP and an external device.
Baud Rate	Select the serial communication speed between the TOP and an external device.
Data Bit	Select the serial communication data bit between the TOP and an external device.
Stop Bit	Select the serial communication stop bit between the TOP and an external device.
Parity Bit	Select the serial communication parity bit check method between the TOP and an external device.

(2) Communication option setting

■ [Main Screen > Control Panel > PLC]



Items	Settings	Remarks
Interface	Select "Serial".	Refer to "2. External device selection".
Protocol	Select the communication protocol between the TOP and an external device.	
TimeOut (ms)	Set the time for the TOP to wait for a response from an external device.	
SendWait (ms)	Set the waiting time between TOP's receiving a response from an external device and sending the next command request.	
Station Num	Set the TOP (Slave) prefix.	
AccessMemoryRange		
0 Devie	0 Device ADDRESS Range Setting	
1 Devie	1 Device ADDRESS Range Setting	
3 Devie	3 Device ADDRESS Range Setting	
4 Devie	4 Device ADDRESS Range Setting	
PacketCountSystemBuffer		
ReadPacketCount	ReadPacket Count	
WritePacketCount	WritPacket Count	
[32BIT SWAP]	Not used, used	

[32BIT SWAP] Changing Unuse to Use will activate the options below.



[32Bit Swap]

Use

32Bit Swap Mode

SwapAddressRange ~

Swap Address Count

-----Swap-SysAddr 1-----

-----Swap-SysAddr 2-----

- 32 BIT SWAP MODE

Big Endian Format(4 3 2 1)

Big Endian With byte-swapped(3 4 1 2)

Little Endian Format(1 2 3 4)

Little Endian With byte-swapped(2 1 4 3)

Put the 4 forms of data on the master and the default value is Little Endian With byte-swapped (2 1 4 3).

- SwapAddressRange

The swap sytembuffer range. If you don't intend to use it use 1 to 0

- SwapAddressCount

You can choose individually, and not scope. Choose from 1-9.

3.3 Communication diagnostics

- Check the interface setting status between the TOP and an external device.

- Touch the top of the TOP screen and drag it down. Touch "EXIT" in the pop-up window to go to the main screen.
- From [Control panel> Serial], confirm that the COM port settings you want to use are the same as the external device

■ Diagnosis of whether the port communication is normal or not

- Touch "Communication diagnostics" in [Control Panel > PLC].
- The Diagnostics dialog box pops up on the screen and determines the diagnostic status.

OK	Communication setting normal
Time Out Error	Communication setting abnormal - Check the cable, TOP, and external device setting status. (Reference: Communication diagnostics sheet)

■ Communication diagnostics sheet

- If there is a problem with the communication connection with an external terminal, please check the settings in the sheet below.

Items	Contents	Check		Remarks	
System configuration	How to connect the system	OK	NG	1. System configuration	
	Connection cable name	OK	NG		
TOP	Version information	OK	NG	2. External device selection 3. Communication setting	
	Port in use	OK	NG		
	Driver name	OK	NG		
	Other detailed settings	OK	NG		
	Relative prefix	Project setting	OK		NG
		Communication diagnostics	OK		NG
	Serial Parameter	Transmission Speed	OK		NG
		Data Bit	OK		NG
Stop Bit		OK	NG		
Parity Bit		OK	NG		
External device	CPU name	OK	NG	4. External device setting	
	Communication port name (module name)	OK	NG		
	Protocol (mode)	OK	NG		
	Setup Prefix	OK	NG		
	Other detailed settings	OK	NG		
	Serial Parameter	Transmission Speed	OK		NG
		Data Bit	OK		NG
		Stop Bit	OK		NG
Parity Bit		OK	NG		
Check address range		OK	NG	6. Supported addresses (For details, please refer to the PLC vendor's manual.)	

4. External device setting

Refer to the user manual of the external device to set "HYOSUNG MODBUS Serial Slave Driver" in the external device I/F.





- Take caution when selecting RTU/ASCII mode in Protocol Frame format.
 - Check the contents of the address map on the external device side and use the communication address according to its contents.
-

5. Cable table



This chapter introduces a cable diagram for normal communication between the TOP and the corresponding device.
(The cable diagrams described in this section may differ from the external device vendor's recommendations.)

■ RS-232C (1:1 connection)

COM			Cable connection	PLC	
Pin arrangement* Note 1)	Signal name	Pin number		Signal name	
 <p>Based on communication cable connector front, D-SUB 9 Pin male (male, convex)</p>	CD	1			
	RD	2		SD	
	SD	3		RD	
	DTR	4		DTR	
	SG	5		SG	
	DSR	6		DSR	
	RTS	7		RTS	
	CTS	8		CTS	
		9			



***Note 1)** The pin arrangement is as seen from the connecting side of the cable connection connector.

■ RS-422 (1:1 connection)

COM			Cable connection	PLC	
Pin arrangement* Note 1)	Signal name	Pin number		Signal name	
 <p>Based on communication cable connector front, D-SUB 9 Pin male (male, convex)</p>	RDA(+)	1		SDA(+)	
		2		SDB(-)	
		3		RDA(+)	
	RDB(-)	4		RDB(-)	
	SG	5		SG	
	SDA(+)	6			
		7			
		8			
	SDB(-)	9			

***Note 1)** The pin arrangement is as seen from the connecting side of the cable connection connector.


■ RS-485 (1:1 connection)

COM			Cable connection	PLC	
Pin arrangement* Note 1)	Signal name	Pin number		Signal name	
 <p>Based on communication cable connector front, D-SUB 9 Pin male (male, convex)</p>	RDA(+)	1		SDA(+)	
		2		SDB(-)	
		3		RDA(+)	
	RDB(-)	4		RDB(-)	
	SG	5		SG	
	SDA(+)	6			
		7			
		8			
	SDB(-)	9			


***Note 1)** The pin arrangement is as seen from the connecting side of the cable connection connector.

☞ Continued on next page.


■ RS-485 (1:1 connection)



■ RS-422 (1:N connection) – Refer to 1:1 connection to connect in the following way.



■ RS-485 (1:N/N:1 connection) – Refer to 1:1 connection to connect in the following way.



6. Supported addresses

The devices available in TOP are as follows:

The device range (address) may differ depending on the CPU module series/type. The TOP series supports the maximum address range used by the external device series. Please refer to each CPU module user manual and be take caution to not deviate from the address range supported by the device you want to use.

	Bit Address	Word Address	32 bits	Remarks
Coil	00000.00 – 10239.15	00000 – 10239	L/H	
Discrete Input	00000.00 – 10239.15	00000 – 10239		*Note 1)
Input Register	00000.00 – 10239.15	00000 – 10239		*Note 1)
Holding Register	00000.00 – 10239.15	00000 – 10239		

***Note 1)** Cannot be written (Read-only)

Maximum SYSTEM BUFFER is 10239

■ "HYOSUNG MODBUS Slave Driver" Support Command (Function) Table

Descriptions	Code	Descriptions	Code	Descriptions	Code
Read Coils	01	Diagnostics (Homing)	08	Write File Record (Homing)	15
Read Discrete Inputs	02	Get Comm Event Counter (Homing)	0B	Mask Write Register (Homing)	16
Read Holding Registers	03	Get Comm Event Log (Homing)	0C	Read/Write Multiple registers (Homing)	17
Read Input Registers	04	Write Multiple Coils	0F	Read FIFO Queue (Homing)	18
Write Single Coil	05	Write Multiple registers	10	Encapsulated I/F Transport (Homing)	2B
Write Single Register	06	Report Slave ID (Homing)	11		
Read Exception Status (Homing)	07	Read File Record (Homing)	14		