

Model	Color/Mono	Interface
HP Pagewide Enterprise Color 765dn	Color	USB, Network
HP DeskJet 3700 All-in-one	Color	USB, Network
HP DeskJet 3722 All-in-one	Color	USB, Network
HP DeskJet Ink Advantage 3735 All-in-one	Color	USB, Network
HP DeskJet Ink Advantage 3789 All-in-one	Color	USB, Network
HP DeskJet Ink Advantage 3790 All-in-one	Color	USB, Network
HP Envy 5000 All-in-one	Color	USB, Network
HP Envy 5020 All-in-one	Color	USB, Network
HP Envy 5030 All-in-one	Color	USB, Network
HP Envy 5032 All-in-one	Color	USB, Network
HP DeskJet Ink Advantage 5075 All-in-one	Color	USB, Network
HP OfficeJet 5200 All-in-one	Color	USB, Network
HP OfficeJet 5220 All-in-one	Color	USB, Network
HP OfficeJet 5230 All-in-one	Color	USB, Network
HP OfficeJet 5232 All-in-one	Color	USB, Network
HP Envy Photo 6200 All-in-one	Color	USB, Network
HP Envy Photo 6220 All-in-one	Color	USB, Network
HP Envy Photo 6230 All-in-one	Color	USB, Network
HP Envy Photo 6232 All-in-one	Color	USB, Network
HP Envy Photo 6234 All-in-one	Color	USB, Network
HP Envy Photo 7100 All-in-one	Color	USB, Network
HP Envy Photo 7120 All-in-one	Color	USB, Network
HP Envy Photo 7130 All-in-one	Color	USB, Network
HP Envy Photo 7134 All-in-one	Color	USB, Network
HP Envy Photo 7155 All-in-one	Color	USB, Network
HP Envy Photo 7164 All-in-one	Color	USB, Network
HP OfficeJet Pro 7730 Wide Format All-in-one	Color	USB, Network
HP Envy Photo 7800 All-in-one	Color	USB, Network
HP Envy Photo 7820 All-in-one	Color	USB, Network
HP Envy Photo 7830 All-in-one	Color	USB, Network
HP Envy Photo 7855 All-in-one	Color	USB, Network
HP Pagewide Managed Color e75160dn	Color	USB, Network
HP DeskJet 2622 All-in-one	Color	USB, Network
HP DeskJet 2200 All-in-one	Color	USB
HP DeskJet Ink Advantage 2676 All-in-one	Color	USB, Network
HP DeskJet Ink Advantage 2635 All-in-one	Color	USB, Network
HP DeskJet 3700 All-in-one	Color	USB, Network
HP DeskJet Ink Advantage 2636 All-in-one	Color	USB, Network
HP DeskJet 3722 All-in-one	Color	USB, Network
HP DeskJet Ink Advantage 2675 All-in-one	Color	USB, Network
HP DeskJet 2623 All-in-one	Color	USB, Network
HP DeskJet Ink Advantage 2678 All-in-one	Color	USB, Network

HP DeskJet Ink Advantage 2677 All-in-one	Color	USB, Network
HP DeskJet 2621 All-in-one	Color	USB, Network
HP DeskJet 2620 All-in-one	Color	USB, Network
HP DeskJet Ink Advantage 3789 All-in-one	Color	USB, Network
HP DeskJet Ink Advantage 3790 All-in-one	Color	USB, Network
HP LaserJet Managed e60065dn	Mono	USB; Network
HP LaserJet Managed e60065x	Mono	USB; Network
HP LaserJet Enterprise m607n	Mono	USB; Network
HP LaserJet Managed e60055dn	Mono	USB; Network
HP LaserJet Enterprise m609x	Mono	USB; Network
HP Pagewide Pro 750dw	Color	USB, Network
HP Pagewide Managed MFP p77740zs	Color	USB, Network
HP LaserJet Managed e60075x	Mono	USB; Network
HP LaserJet Managed e60075dn	Mono	USB; Network
HP Color LaserJet Managed e65060dn	Color	USB, Network
HP LaserJet Enterprise m609dn	Mono	USB; Network
HP Color LaserJet Enterprise m653x	Color	USB, Network
HP Pagewide Pro MFP 772dw	Color	USB, Network
HP Color LaserJet Enterprise m652n	Color	USB, Network
HP LaserJet Enterprise m608dh	Mono	USB; Network
HP LaserJet Enterprise m608dn	Mono	USB; Network
HP Color LaserJet Enterprise m653dh	Color	USB, Network
HP LaserJet Enterprise m608x	Mono	USB; Network
HP Color LaserJet Enterprise m653dn	Color	USB, Network
HP Pagewide Managed p75050dn	Color	USB, Network
HP Pagewide Pro 750dn	Color	USB, Network
HP Pagewide Managed MFP p77750zs	Color	USB, Network
HP Pagewide Managed MFP p77750zs	Color	USB, Network
HP LaserJet Enterprise m607dn	Mono	USB; Network
HP LaserJet Enterprise m608n	Mono	USB; Network
HP Color LaserJet Enterprise m652dn	Color	USB, Network
HP Color LaserJet Managed e65050dn	Color	USB, Network
HP Pagewide Managed MFP p77750z	Color	USB, Network
HP LaserJet Pro MFP m132a	Mono	USB; Network
HP LaserJet Pro m206dn	Mono	USB; Network
HP LaserJet Pro MFP m134fn	Mono	USB; Network
HP LaserJet Ultra MFP m230sdn	Mono	USB; Network
HP LaserJet m102w	Mono	USB; Network
HP LaserJet m102a	Mono	USB; Network
HP LaserJet Pro MFP m130a	Mono	USB; Network
HP LaserJet Pro m203d	Mono	USB; Network
HP LaserJet Pro MFP m227fdn	Mono	USB; Network
HP LaserJet Pro MFP m227fdw	Mono	USB; Network

HP LaserJet m104w	Mono	USB; Network
HP LaserJet m104a	Mono	USB; Network
HP LaserJet Pro MFP m132fw	Mono	USB; Network
HP LaserJet Pro MFP m132fp	Mono	USB; Network
HP LaserJet Pro MFP m132fn	Mono	USB; Network
HP LaserJet Pro MFP m132nw	Mono	USB; Network
HP LaserJet Pro MFP m227d	Mono	USB; Network
HP LaserJet m106w	Mono	USB; Network
HP LaserJet Pro MFP m134a	Mono	USB; Network
HP LaserJet Pro MFP m227sdn	Mono	USB; Network
HP LaserJet Pro MFP m132snw	Mono	USB; Network
HP LaserJet Pro m203dw	Mono	USB; Network
HP LaserJet Pro m203dw	Mono	USB; Network
HP LaserJet Pro MFP m130fw	Mono	USB; Network
HP LaserJet Pro MFP m130nw	Mono	USB; Network
HP LaserJet Pro MFP m130fn	Mono	USB; Network
HP Scanjet Pro 3000 s3	Not	USB; Network
HP Color LaserJet MFP m277c6	Color	USB, Network
HP Scanjet Enterprise Flow 5000 s4	Not	USB; Network
HP Scanjet Enterprise Flow 7000 s3	Not	USB; Network
HP Pagewide Managed Color MFP e58650dn	Color	USB, Network
HP OfficeJet Pro 8732 All-in-one Printer	Color	USB, Network
HP OfficeJet 6960 All-in-one	Color	USB, Network
HP OfficeJet 8702 All-in-one	Color	USB, Network
HP Pagewide Managed Color e55650dn	Color	USB, Network
HP OfficeJet Pro 6970 All-in-one	Color	USB, Network
HP OfficeJet 250 Mobile All-in-one	Color	USB, Network
HP OfficeJet 250c Mobile All-in-one	Color	USB, Network
HP OfficeJet 252c Mobile All-in-one	Color	USB, Network
HP OfficeJet Pro 6978 All-in-one	Color	USB, Network
HP OfficeJet Pro 6960 All-in-one	Color	USB, Network
HP OfficeJet 252 Mobile All-in-one	Color	USB, Network
HP OfficeJet 258 Mobile All-in-one	Color	USB, Network
HP OfficeJet Pro 6975 All-in-one	Color	USB, Network
HP Pagewide Enterprise Color 556dn	Color	USB, Network
HP Pagewide Enterprise Color Flow MFP 586z	Color	USB, Network
HP Color LaserJet MFP m377 Fnw	Color	USB, Network
HP DeskJet Ink Advantage Ultra 5738 All-in-one Printer	Color	USB, Network
HP OfficeJet Pro 8730	Color	USB, Network
HP OfficeJet Pro 8210	Color	USB, Network
HP Pagewide Enterprise Color 556xh	Color	USB, Network
HP DeskJet Ink Advantage Ultra 5739 All-in-one Printer	Color	USB, Network
HP Pagewide Managed MFP p57750dw	Color	USB, Network

HP OfficeJet Pro 8720 All-in-one Printer	Color	USB, Network
HP OfficeJet Pro 8725 All-in-one Printer	Color	USB, Network
HP OfficeJet Pro 8710 All-in-one Printer	Color	USB, Network
HP OfficeJet Pro 8740 All-in-one Printer	Color	USB, Network
HP LaserJet Pro m501dn	Color	USB, Network
HP LaserJet Pro m501n	Color	USB, Network
HP OfficeJet Pro 8715 All-in-one Printer	Color	USB, Network
HP OfficeJet 200 Mobile Printer	Color	USB, Network
HP DeskJet Gt 5820 All-in-one Printer	Color	USB, Network
HP Pagewide Pro 477dn Multifunction Printer	Color	USB, Network
HP Pagewide Pro 577z Multifunction Printer	Color	USB, Network
HP Pagewide Pro 577dw Multifunction Printer	Color	USB, Network
HP Pagewide Pro 477dw Multifunction Printer	Color	USB, Network
HP Pagewide Pro 452dw Printer	Color	USB, Network
HP Pagewide Pro 552dw Printer	Color	USB, Network
HP DeskJet Gt 5810 All-in-one Printer	Color	USB
HP Pagewide Pro 452dn Printer	Color	USB, Network
HP Scanjet Pro 4500 fn1	Not	USB; Network
HP LaserJet Pro MFP m127fs	Mono	USB; Network
HP DeskJet Ink Advantage 4535 All-in-one	Color	USB, Network
HP Color LaserJet Enterprise MFP m577 Series	Color	USB, Network
HP DeskJet Ink Advantage Ultra 4720 All-in-one Printer Series	Color	USB, Network
HP LaserJet Pro m403n	Mono	USB; Network
HP DeskJet Ink Advantage 5645 All-in-one Printer	Not	USB; Network
HP LaserJet Pro m403d	Mono	USB
HP DeskJet Ink Advantage Ultra 4729 All-in-one Printer	Color	USB, Network
HP Scanjet Pro 3500 f1 Flatbed Scanner	Not	USB
HP LaserJet Pro m402n	Mono	USB; Network
HP LaserJet Pro m402d	Mono	USB
HP LaserJet Pro MFP m426fdn	Color	USB, Network
HP DeskJet Ink Advantage 4676 All-in-one	Color	USB, Network
HP Envy 4523 All-in-one Printer	Color	USB, Network
HP LaserJet Enterprise m506x	Color	USB, Network
HP LaserJet Enterprise m506dn	Color	USB, Network
HP LaserJet Enterprise m506dh	Color	USB, Network
HP LaserJet Enterprise MFP m527dn	Color	USB, Network
HP LaserJet Enterprise m506n	Color	USB, Network
HP DeskJet Ink Advantage 4670 All-in-one	Color	USB, Network
HP Color LaserJet Enterprise Flow MFP m577 Series	Color	USB, Network
HP DeskJet Ink Advantage 5570 All-in-one	Color	USB, Network
HP Color LaserJet Pro MFP m477 Fdn	Color	USB, Network
HP Color LaserJet Pro m452nw	Color	USB, Network
HP Color LaserJet Pro MFP m477 Fdw	Color	USB, Network

HP LaserJet Enterprise MFP m527f	Color	USB, Network
HP Color LaserJet Enterprise MFP m577f	Color	USB, Network
HP LaserJet Pro MFP m427dw	Color	USB, Network
HP LaserJet Pro m402-m403 Series	Mono	USB
HP LaserJet Pro m402-m403 N-dn Series	Mono	USB; Network
HP LaserJet Pro MFP m427dn	Color	USB, Network
HP LaserJet Enterprise Flow MFP m527z	Color	USB, Network
HP LaserJet Enterprise Flow MFP m527c	Color	USB, Network
HP LaserJet Enterprise m506 Series	Color	USB, Network
HP DeskJet Ink Advantage 4530 All-in-one	Color	USB, Network
HP DeskJet Ink Advantage 5640 All-in-one Printer Series	Not	USB; Network
HP LaserJet Pro MFP m426dw	Color	USB, Network
HP Envy 4520 All-in-one Printer	Color	USB, Network
HP Envy 4524 All-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 4536 All-in-one	Color	USB, Network
HP Color LaserJet Pro m452dn	Color	USB, Network
HP Color LaserJet Enterprise Flow MFP m577c	Color	USB, Network
HP Color LaserJet Enterprise Flow MFP m577z	Color	USB, Network
HP Color LaserJet Pro m452dw	Color	USB, Network
HP LaserJet Pro m402dw	Mono	USB; Network
HP LaserJet Pro m402dw	Mono	USB; Network
HP Envy 4522 All-in-one Printer	Color	USB, Network
HP LaserJet Pro m403dw	Mono	USB; Network
HP LaserJet Pro m403dw	Mono	USB; Network
HP DeskJet Ink Advantage 5575 All-in-one	Color	USB, Network
HP LaserJet Pro m403dn	Mono	USB; Network
HP LaserJet Pro m403dn	Mono	USB; Network
HP Envy 4520 All-in-one Printer Series	Color	USB, Network
HP Envy 4520 All-in-one Printer Series	Color	USB, Network
HP Color LaserJet Enterprise MFP m577dn	Color	USB, Network
HP LaserJet Pro MFP m426fdw	Color	USB, Network
HP Color LaserJet Pro MFP m477 Fnw	Color	USB, Network
HP LaserJet Pro m402dn	Mono	USB; Network
HP LaserJet Pro m402dn	Mono	USB; Network
HP Color LaserJet Pro MFP m274n	Color	USB, Network
HP DeskJet Ink Advantage 4675 All-in-one	Color	USB, Network
HP LaserJet Pro MFP m427fdw	Color	USB, Network
HP Envy 5543 All-in-one Printer	Color	USB, Network
HP OfficeJet 4654 All-in-one Printer	Color	USB, Network
HP Envy 4516 All-in-one	Color	USB, Network
HP Envy 4510 All-in-one	Color	USB, Network
HP Envy 5542 E-all-in-one Printer	Color	USB, Network
HP OfficeJet 4652 All-in-one Printer	Color	USB, Network

HP Envy 5545 E-all-in-one Printer	Color	USB, Network
HP Envy 4512 All-in-one	Color	USB, Network
HP OfficeJet 4650 All-in-one Printer	Color	USB, Network
HP Envy 5544 All-in-one Printer	Color	USB, Network
HP Pagewide 352dw Printer	Color	USB, Network
HP OfficeJet 4650 All-in-one Printer Series	Color	USB, Network
HP OfficeJet 4650 All-in-one Printer Series	Color	USB, Network
HP Envy 5540 All-in-one Printer Series	Color	USB, Network
HP Envy 5540 All-in-one Printer Series	Color	USB, Network
HP Pagewide MFP 377dw	Color	USB, Network
HP Envy 5540 All-in-one Printer	Color	USB, Network
HP OfficeJet 4655 All-in-one Printer	Color	USB, Network
HP Envy 5546 All-in-one Printer	Color	USB, Network
HP OfficeJet 3832 All-in-one Printer	Color	USB, Network
HP DeskJet 1112 Printer	Color	USB
HP DeskJet Ink Advantage 3836 All-in-one Printer	Color	USB, Network
HP OfficeJet 3834 All-in-one Printer	Color	USB, Network
HP OfficeJet 3830 All-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 1110 Printer	Color	USB
HP DeskJet 1111 Printer	Color	USB
HP DeskJet Ink Advantage 1118 Printer	Color	USB
HP DeskJet 1110 Printer	Color	USB
HP OfficeJet 7510 Wide Format E-all-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 3835 All-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 3830 All-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 1115 Printer	Color	USB
HP DeskJet 3633 All-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 3635 All-in-one Printer	Color	USB, Network
HP DeskJet 2134 All-in-one Printer	Color	USB
HP DeskJet 2132 All-in-one Printer	Color	USB
HP DeskJet Ink Advantage 2136 All-in One Printer	Color	USB
HP DeskJet Ink Advantage 2138 All-in One Printer	Color	USB
HP DeskJet Ink Advantage 2130 All-in One Printer	Color	USB
HP DeskJet Ink Advantage 2135 All-in One Printer	Color	USB
HP DeskJet 3634 All-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 3636 All-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 3638 All-in-one Printer	Color	USB, Network
HP DeskJet 3630 All-in-one Printer	Color	USB, Network
HP DeskJet 2131 All-in-one Printer	Color	USB
HP DeskJet Ink Advantage 3630 All-in-one Printer	Color	USB, Network
HP DeskJet 2130 All-in-one Printer Series	Color	USB
HP DeskJet 3632 All-in-one Printer	Color	USB, Network
HP LaserJet Enterprise m606dn	Mono	USB; Network

HP Color LaserJet Pro m252dw	Color	USB, Network
HP Color LaserJet Enterprise m552dn	Color	USB, Network
HP Color LaserJet Enterprise m553n	Color	USB, Network
HP LaserJet Enterprise m605x	Mono	USB; Network
HP Color LaserJet MFP m277n	Color	USB, Network
HP LaserJet Enterprise m605n	Mono	USB; Network
HP Color LaserJet Enterprise m553x	Color	USB, Network
HP Color LaserJet Enterprise m553dh	Color	USB, Network
HP Color LaserJet Enterprise m553dn	Color	USB, Network
HP LaserJet Enterprise m604n	Mono	USB; Network
HP Color LaserJet MFP m277dw	Color	USB, Network
HP LaserJet Enterprise m604dn	Mono	USB; Network
HP LaserJet Enterprise m605dn	Mono	USB; Network
HP LaserJet Enterprise m606x	Mono	USB; Network
HP Color LaserJet Pro m252n	Color	USB, Network
HP OfficeJet Pro 6835 E-all-in-one	Color	USB, Network
HP OfficeJet 8040 E-all-in-one	Color	USB, Network
HP Envy 7645 E-all-in-one	Color	USB, Network
HP LaserJet Pro MFP m225dw	Mono	USB; Network
HP Envy 7640 E-all-in-one	Color	USB, Network
HP LaserJet Pro MFP m225rdn	Mono	USB; Network
HP OfficeJet 5745 E-all-in-one	Color	USB, Network
HP LaserJet Pro MFP m225dn	Mono	USB; Network
HP OfficeJet 5740 E-all-in-one	Color	USB, Network
HP Envy 5644 E-all-in-one	Not	USB; Network
HP OfficeJet 6800 E-all-in-one	Color	USB, Network
HP LaserJet Pro m201n Printer	Mono	USB; Network
HP OfficeJet 5744 E-all-in-one	Color	USB, Network
HP LaserJet Pro MFP m125r	Mono	USB
HP LaserJet Pro m202n Printer	Mono	USB; Network
HP LaserJet Pro MFP m226dn	Mono	USB; Network
HP OfficeJet 5742 E-all-in-one	Color	USB, Network
HP OfficeJet 6950 All-in-one	Color	USB, Network
HP LaserJet Pro m201dw Printer	Mono	USB; Network
HP OfficeJet Pro 6230 Eprinter	Color	USB, Network
HP OfficeJet 6820 E-all-in-one Printer	Color	USB, Network
HP OfficeJet 6815 E-all-in-one Printer	Color	USB, Network
HP OfficeJet 6812 E-all-in-one Printer	Color	USB, Network
HP OfficeJet 6810 E-all-in-one Printer Series	Color	USB, Network
HP Envy 5665 E-all-in-one	Not	USB; Network
HP Envy 5643 E-all-in-one	Not	USB; Network
HP Envy 5660 E-all-in-one	Not	USB; Network
HP LaserJet Pro MFP m226dw	Mono	USB; Network

HP Envy 5640 E-all-in-one	Not	USB; Network
HP Envy 5642 E-all-in-one	Not	USB; Network
HP LaserJet Pro m202dw Printer	Mono	USB; Network
HP OfficeJet Pro 6830 E-all-in-one	Color	USB, Network
HP LaserJet Pro MFP m125ra	Mono	USB
HP LaserJet Pro MFP m125ra	Mono	USB
HP OfficeJet Pro 8640 E-all-in-one Printer	Color	USB, Network
HP OfficeJet Pro 8660 E-all-in-one Printer	Color	USB, Network
HP OfficeJet Pro 8620 E-all-in-one Printer	Color	USB, Network
HP LaserJet Pro MFP m128fn	Mono	USB; Network
HP OfficeJet Pro 8610 E-all-in-one Printer	Color	USB, Network
HP LaserJet Pro m706n Printer	Mono	USB; Network
HP Color LaserJet Pro MFP m476dn	Color	USB, Network
HP Color LaserJet Pro MFP m476nw	Color	USB, Network
HP LaserJet Pro MFP m128fp	Mono	USB; Network
HP OfficeJet Enterprise Color x585f Multifunction Printer	Color	USB, Network
HP OfficeJet Pro 8616 E-all-in-one Printer	Color	USB, Network
HP OfficeJet Pro 8630 E-all-in-one Printer	Color	USB, Network
HP Color LaserJet Enterprise Multifunction m680f Printer	Color	USB, Network
HP Color LaserJet Enterprise Flow Multifunction m680z Printer	Color	USB, Network
HP Color LaserJet Pro MFP m476dw	Color	USB, Network
HP Color LaserJet Enterprise m651dn Printer	Color	USB, Network
HP OfficeJet Enterprise Color x555dn Printer	Color	USB, Network
HP LaserJet Pro MFP m128fw	Mono	USB; Network
HP Color LaserJet Enterprise m651n Printer	Color	USB, Network
HP LaserJet Pro m701n Printer	Mono	USB; Network
HP Color LaserJet Enterprise m651xh Printer	Color	USB, Network
HP OfficeJet Pro 8615 E-all-in-one Printer	Color	USB, Network
HP OfficeJet Enterprise Color x585dn Multifunction Printer	Color	USB, Network
HP LaserJet Pro m701a Printer	Mono	USB
HP OfficeJet Enterprise Color x555xh Printer	Color	USB, Network
HP Designjet t795 44-in Eprinter	Color	USB, Network
HP Color LaserJet Enterprise Multifunction m680dn Printer	Color	USB, Network
HP OfficeJet Pro 8625 E-all-in-one Printer	Color	USB, Network
HP OfficeJet Enterprise Color Flow x585z Multifunction Printer	Color	USB, Network
HP LaserJet Pro MFP m126a	Mono	USB
HP LaserJet Pro MFP m125rnw	Mono	USB; Network
HP LaserJet Pro MFP m125rnw	Mono	USB; Network
HP DeskJet Ink Advantage 4640 E-all-in-one Printer Series	Color	USB, Network
HP LaserJet Pro MFP m125nw	Mono	USB; Network
HP DeskJet Ink Advantage 4645 E-all-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 4648 E-all-in-one Printer	Color	USB, Network
HP LaserJet Pro MFP m126nw	Mono	USB; Network

HP LaserJet Pro MFP m125a	Mono	USB
HP DeskJet Ink Advantage 4646 E-all-in-one Printer	Color	USB, Network
HP LaserJet Pro MFP m127fp	Mono	USB; Network
HP OfficeJet 2621 All-in-one	Color	USB
HP Color LaserJet Enterprise Flow m880z Multifunction Printer	Color	USB, Network
HP Color LaserJet Pro Mpf m177fw	Color	USB, Network
HP Color LaserJet Enterprise m855x+ Printer	Color	USB, Network
HP Color LaserJet Enterprise Flow m880z+ Multifunction	Color	USB, Network
HP LaserJet Pro MFP m127fn	Mono	USB; Network
HP Color LaserJet Enterprise m750 Printer Series	Color	USB, Network
HP OfficeJet 2622 All-in-one	Color	USB
HP LaserJet Pro MFP m127fw	Mono	USB; Network
HP Color LaserJet Pro Mpf m176n	Color	USB, Network
HP Color LaserJet Enterprise m855dn Printer	Color	USB, Network
HP Color LaserJet Enterprise m750dn	Color	USB, Network
HP Color LaserJet Enterprise m855 Printer Series	Color	USB, Network
HP Color LaserJet Enterprise Flow m880 Multifunction Printer	Color	USB, Network
HP OfficeJet 2620 All-in-one	Color	USB
HP Color LaserJet Enterprise m750n	Color	USB, Network
HP Color LaserJet Enterprise m750xh	Color	USB, Network
HP Color LaserJet Enterprise m855xh Printer	Color	USB, Network
HP LaserJet Enterprise m806 Printer Series	Mono	USB; Network
HP LaserJet Enterprise Flow m830 Multifunction Printer Series	Mono	USB; Network
HP DeskJet Ink Advantage 2645 All-in-one Printer	Color	USB
HP LaserJet Enterprise Flow m830z Multifunction Printer	Mono	USB; Network
HP DeskJet Ink Advantage 2646 All-in-one Printer	Color	USB
HP LaserJet Enterprise m806dn Printer	Mono	USB; Network
HP LaserJet Enterprise m806x+ Printer	Mono	USB; Network
HP DeskJet Ink Advantage 4518 E-all-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 4515 E-all-in-one Printer	Color	USB, Network
HP OfficeJet 4630 E-all-in-one Printer	Color	USB, Network
HP OfficeJet 4631 E-all-in-one Printer	Color	USB, Network
HP LaserJet Pro MFP m435nw	Mono	USB; Network
HP OfficeJet 4632 E-all-in-one Printer	Color	USB, Network
HP OfficeJet 4636 E-all-in-one Printer	Color	USB, Network
HP OfficeJet 4635 E-all-in-one Printer	Color	USB, Network
HP OfficeJet 4634 E-all-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 3540 E-all-in-one Printer Series	Color	USB, Network
HP DeskJet 2541 All-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 3545 E-all-in-one Printer	Color	USB, Network
HP DeskJet 2546b All-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 1515 All-in-one Printer	Color	USB
HP DeskJet Ink Advantage 2548 All-in-one Printer	Color	USB, Network

HP DeskJet Ink Advantage 2546 All-in-one Printer	Color	USB, Network
HP DeskJet 2540 All-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 2540 All-in-one Printer Series	Color	USB, Network
HP DeskJet 2542 All-in-one Printer	Color	USB, Network
HP DeskJet 1512 All-in-one Printer	Color	USB
HP DeskJet 2544 All-in-one Printer	Color	USB, Network
HP DeskJet 1513 All-in-one Printer	Color	USB
HP DeskJet 1510 All-in-one Printer	Color	USB
HP DeskJet Ink Advantage 1510 All-in-one Printer Series	Color	USB
HP DeskJet Ink Advantage 1516 All-in-one Printer	Color	USB
HP DeskJet 2546p All-in-one Printer	Color	USB, Network
HP DeskJet 2549 All-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 3546 E-all-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 1518 All-in-one Printer	Color	USB
HP DeskJet 2546r All-in-one Printer	Color	USB, Network
HP DeskJet 1511 All-in-one Printer	Color	USB
HP DeskJet 1514 All-in-one Printer	Color	USB
HP DeskJet 2545 All-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 2545 All-in-one Printer	Color	USB, Network
HP DeskJet 2543 All-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 1015 Printer	Color	USB
HP DeskJet 1012 Printer	Color	USB
HP Envy 5535 E-all-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 1010 Printer Series	Color	USB
HP DeskJet Ink Advantage 1018 Printer	Color	USB
HP DeskJet 1011 Printer	Color	USB
HP Envy 5534 E-all-in-one Printer	Color	USB, Network
HP Envy 5536 E-all-in-one Printer	Color	USB, Network
HP OfficeJet 7612 Wide Format E-all-in-one Printer	Color	USB, Network
HP Envy 5532 E-all-in-one Printer	Color	USB, Network
HP OfficeJet 7610 Wide Format E-all-in-one Printer	Color	USB, Network
HP Envy 5539 E-all-in-one Printer	Color	USB, Network
HP Envy 5530 E-all-in-one Printer	Color	USB, Network
HP Envy 5531 E-all-in-one Printer	Color	USB, Network
HP DeskJet 1010 Printer	Color	USB
HP Envy 4504 E-all-in-one	Color	USB, Network
HP Envy 4501 E-all-in-one	Color	USB, Network
HP Envy 4505 E-all-in-one	Color	USB, Network
HP Envy 4508 E-all-in-one	Color	USB, Network
HP Envy 4503 E-all-in-one	Color	USB, Network
HP Envy 4502 E-all-in-one	Color	USB, Network
HP Envy 4500 E-all-in-one	Color	USB, Network
HP Envy 4507 E-all-in-one	Color	USB, Network

HP LaserJet Enterprise MFP m725dn	Mono	USB; Network
HP LaserJet Enterprise MFP m725z+	Mono	USB; Network
HP LaserJet Enterprise MFP m725z+	Mono	USB; Network
HP OfficeJet Pro 3620 Black And White E-all-in-one	Mono	USB; Network
HP OfficeJet Pro 3610 Black And White E-all-in-one	Mono	USB; Network
HP LaserJet Enterprise MFP m725fw	Mono	USB; Network
HP LaserJet Enterprise MFP m725z	Mono	USB; Network
HP LaserJet Enterprise MFP m725 Series	Mono	USB; Network
HP Designjet z5200 44-in Postscript Printer	Color	USB, Network
HP OfficeJet Pro 251dw Printer	Color	USB, Network
HP LaserJet Pro m521dn Multifunction Printer	Mono	USB; Network
HP OfficeJet Pro 276dw Multifunction Printer	Color	USB, Network
HP LaserJet Pro m521dw Multifunction Printer	Mono	USB; Network
HP OfficeJet Pro x476dw Multifunction Printer	Color	USB, Network
HP OfficeJet Pro x551dw Printer	Color	USB, Network
HP OfficeJet Pro x476 Multifunction Printer Series	Color	USB, Network
HP OfficeJet Pro x451dw Printer	Color	USB, Network
HP OfficeJet Pro x576dw Multifunction Printer	Color	USB, Network
HP OfficeJet Pro x551 Printer Series	Color	USB, Network
HP OfficeJet Pro x576 Multifunction Printer Series	Color	USB, Network
HP OfficeJet Pro x451dn Printer	Color	USB, Network
HP OfficeJet 7110 Wide Format Eprinter	Color	USB, Network
HP OfficeJet Pro x476dn Multifunction Printer	Color	USB, Network
HP LaserJet 400 m401dne	Mono	USB; Network
HP LaserJet 400 m401dne	Mono	USB; Network
HP LaserJet 400 m401dne	Mono	USB; Network
HP OfficeJet Pro x451 Printer Series	Color	USB, Network
HP LaserJet Enterprise 700 Color MFP m775dn	Color	USB, Network
HP LaserJet Enterprise Color Flow MFP m575	Color	USB, Network
HP LaserJet Enterprise 700 Color MFP m775z	Color	USB, Network
HP LaserJet Enterprise 700 Color MFP m775f	Color	USB, Network
HP LaserJet Enterprise 700 Color MFP m775z+	Color	USB, Network
HP LaserJet Enterprise 700 Color MFP m775z+	Color	USB, Network
HP LaserJet Pro 500 Color MFP m570dw	Color	USB, Network
HP LaserJet Pro 500 Color MFP m570dn	Color	USB, Network
HP LaserJet Enterprise Flow MFP m525	Color	USB, Network
HP LaserJet Enterprise 700 m712n	Mono	USB; Network
HP LaserJet Enterprise 700 m712xh	Mono	USB; Network
HP LaserJet Enterprise 700 m712dn	Mono	USB; Network
HP OfficeJet 150 Mobile All-in-one	Color	USB
HP Envy 120 E-all-in-one	Color	USB, Network
HP DeskJet Ultra Ink Advantage 2029 Printer	Color	USB
HP DeskJet Ink Advantage 2020hc Printer	Color	USB

HP Envy 121 E-all-in-one	Color	USB, Network
HP LaserJet m1210 MFP Series	Mono	USB; Network
HP Hotspot LaserJet Pro m1218nfs MFP	Mono	USB; Network
HP DeskJet Ink Advantage 2520hc All-in-one	Color	USB
HP DeskJet Ink Advantage Ultra 2529 All-in-one Printer	Color	USB
HP PhotoSmart 7520 E-all-in-one	Color	USB, Network
HP DeskJet 3512 E-all-in-one	Color	USB, Network
HP DeskJet Ink Advantage 6525 E-all-in-one	Color	USB, Network
HP DeskJet 3510 E-all-in-one	Color	USB, Network
HP PhotoSmart 6525 E All-in-one	Color	USB, Network
HP DeskJet Ink Advantage 3516 E-all-in-one	Color	USB, Network
HP LaserJet Pro 200 Color MFP m276n	Color	USB, Network
HP LaserJet Pro m251n Color Printer	Color	USB, Network
HP DeskJet 3511 E-all-in-one	Color	USB, Network
HP LaserJet Pro 200 Color MFP m276nw	Color	USB, Network
HP LaserJet Pro 200 Color MFP m276nw	Color	USB, Network
HP DeskJet Ink Advantage 3515 E-all-in-one	Color	USB, Network
HP PhotoSmart 6520 E All-in-one	Color	USB, Network
HP LaserJet Pro m251nw Color Printer	Color	USB, Network
HP PhotoSmart 7525 E-all-in-one	Color	USB, Network
HP LaserJet Professional m1139 Multifunction Printer	Mono	USB
HP DeskJet Ink Advantage 4625 E-all-in-one Printer	Color	USB, Network
HP LaserJet Professional m1137 Multifunction Printer	Mono	USB
HP LaserJet Enterprise 500 Color MFP m575dn	Color	USB, Network
HP LaserJet Enterprise 500 Color MFP m575dn	Color	USB, Network
HP LaserJet Enterprise 500 MFP m525f	Color	USB, Network
HP PhotoSmart 5522 E-all-in-one Printer	Color	USB, Network
HP PhotoSmart 5524 E-all-in-one Printer	Color	USB, Network
HP PhotoSmart 5520 E-all-in-one	Color	USB, Network
HP DeskJet 3520 E-all-in-one Series	Color	USB, Network
HP LaserJet Professional m1138 Multifunction Printer	Mono	USB
HP DeskJet Ink Advantage 2510 All-in-one	Color	USB
HP PhotoSmart 5521 E-all-in-one Printer	Color	USB, Network
HP LaserJet Enterprise 500 MFP m525dn	Color	USB, Network
HP LaserJet 400 m401dn	Mono	USB; Network
HP LaserJet 400 m401dn	Mono	USB; Network
HP DeskJet Ink Advantage 2515 All-in-one Printer	Color	USB
HP LaserJet 400 m401dw	Mono	USB; Network
HP LaserJet 400 m401dw	Mono	USB; Network
HP DeskJet Ink Advantage 4615 All-in-one Printer	Color	USB
HP DeskJet 2512 All-in-one Printer	Color	USB
HP OfficeJet 4620 E-all-in-one Printer	Color	USB, Network
HP LaserJet Professional p1609dn Printer	Mono	USB; Network

HP DeskJet Ink Advantage 4610 All-in-one Printer Series	Color	USB
HP DeskJet 2514 All-in-one Printer	Color	USB
HP DeskJet 3521 E-all-in-one Printer	Color	USB, Network
HP LaserJet Professional p1569	Mono	USB
HP LaserJet Professional p1568	Mono	USB
HP LaserJet Professional p1567	Mono	USB
HP DeskJet 3522 E-all-in-one Printer	Color	USB, Network
HP DeskJet 2510 All-in-one Printer	Color	USB
HP DeskJet Ink Advantage 2516 All-in-one Printer	Color	USB
HP LaserJet 400 m401d	Mono	USB
HP LaserJet 400 m401a	Mono	USB
HP LaserJet 400 m401n	Mono	USB; Network
HP OfficeJet 4610 All-in-one Printer Series	Color	USB
HP LaserJet Professional p1107w Printer	Mono	USB; Network
HP LaserJet Professional p1608dn Printer	Mono	USB; Network
HP LaserJet Enterprise 500 MFP m525 Series	Color	USB, Network
HP LaserJet Professional p1109 Printer	Mono	USB
HP LaserJet Professional P 1102w Printer	Mono	USB; Network
HP DeskJet 3524 E-all-in-one Printer	Color	USB, Network
HP DeskJet 3526 E-all-in-one Printer	Color	USB, Network
HP LaserJet Enterprise 500 Color MFP m575	Color	USB, Network
HP DeskJet Ink Advantage 3525 E-all-in-one	Color	USB, Network
HP DeskJet 2511 All-in-one Printer	Color	USB
HP LaserJet Professional p1107 Printer	Mono	USB
HP LaserJet Professional p1109w Printer	Mono	USB; Network
HP LaserJet 400 MFP m425dw	Mono	USB; Network
HP LaserJet Enterprise 500 Color MFP m575f	Color	USB, Network
HP LaserJet Enterprise 500 Color MFP m575f	Color	USB, Network
HP LaserJet 400 MFP m425dn	Mono	USB; Network
HP LaserJet Professional p1607dn Printer	Mono	USB; Network
HP OfficeJet 4622 E-all-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 4620 E-all-in-one Printer	Color	USB, Network
HP PhotoSmart 5525 E-all-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage 5525 E-all-in-one	Color	USB, Network
HP OfficeJet 6100 Eprinter h611a	Color	USB, Network
HP LaserJet Professional p1106w Printer	Mono	USB; Network
HP OfficeJet 6600 E-all-in-one Printer - h711a	Color	USB, Network
HP OfficeJet 6700 Premium E-all-in-one printer-h711n	Color	USB, Network
HP LaserJet Pro Cp 1025nw Color Printer Series	Color	USB, Network
HP LaserJet Professional p1108w Printer	Mono	USB; Network
HP LaserJet Pro Cp 1025 Color Printer Series	Color	USB
HP LaserJet 300 Color MFP m375nw	Color	USB, Network
HP LaserJet Professional p1106 Printer	Mono	USB

HP LaserJet 400 Color m451dw	Color	USB, Network
HP LaserJet 400 Color m451dn	Color	USB, Network
HP LaserJet Professional p1108 Printer	Mono	USB
HP LaserJet 400 Color m451nw	Color	USB, Network
HP Color LaserJet cp1217 Printer	Color	USB, Network
HP LaserJet 400 Color MFP m475dw	Color	USB, Network
HP LaserJet 400 Color MFP m475dn	Color	USB, Network
HP LaserJet 300 Color m351a	Color	USB
HP LaserJet 200 Color MFP m275s	Color	USB, Network
HP LaserJet 200 Color MFP m275t	Color	USB, Network
HP LaserJet 200 Color MFP m275u	Color	USB, Network
HP LaserJet 200 Color MFP m275nw	Color	USB, Network
HP LaserJet Enterprise 600 m603dn	Mono	USB; Network
HP LaserJet Enterprise 600 m602x	Mono	USB; Network
HP LaserJet Enterprise 600 m602dn	Mono	USB; Network
HP LaserJet Enterprise 600 m602n	Mono	USB; Network
HP LaserJet Enterprise 600 m601n	Mono	USB; Network
HP LaserJet Enterprise 600 m601dn	Mono	USB; Network
HP LaserJet Enterprise 600 m603n	Mono	USB; Network
HP PhotoSmart 5510d E-all-in-one	Color	USB, Network
HP LaserJet Enterprise 600 m603xh	Mono	USB; Network
HP LaserJet Enterprise 500 Color m551	Color	USB, Network
HP PhotoSmart 7510 E-all-in-one	Color	USB, Network
HP DeskJet 3070 b611 Series	Color	USB, Network
HP OfficeJet Pro 8600 E-aio n911a	Color	USB, Network
HP PhotoSmart 6510 E-all-in-one	Color	USB, Network
HP OfficeJet Pro 8600 Plus E-aio n911g	Color	USB, Network
HP OfficeJet Pro 8600 Premium E-aio n911n	Color	USB, Network
HP Envy 111 E-all-in-one	Color	USB, Network
HP PhotoSmart 5510 E-all-in-one	Color	USB, Network
HP OfficeJet Pro 8100 eprinter-n811a	Color	USB, Network
HP Envy 110 E-all-in-one	Color	USB, Network
HP Envy 114 E-all-in-one	Color	USB, Network
HP LaserJet Professional m1219nf MFP	Mono	USB; Network
HP DeskJet 3055a E-all-in-one Printer j611n	Color	USB, Network
HP DeskJet 3052a E-all-in-one Printer j611e	Color	USB, Network
HP LaserJet Professional m1216nfh MFP	Mono	USB; Network
HP DeskJet 3057a E-all-in-one Printer j611n	Color	USB, Network
HP DeskJet 3052a E-all-in-one Printer j611f	Color	USB, Network
HP DeskJet 3056a E-all-in-one Printer	Color	USB, Network
HP DeskJet 3054a E-all-in-one Printer j611j	Color	USB, Network
HP DeskJet 3054a E-all-in-one Printer j611c	Color	USB, Network
HP DeskJet 3052a E-all-in-one Printer j611g	Color	USB, Network

HP DeskJet 3054a E-all-in-one Printer j611d	Color	USB, Network
HP DeskJet 3050a j611 Series	Color	USB, Network
HP LaserJet 100 Color MFP m175	Color	USB
HP DeskJet 3051a E-all-in-one Printer j611h	Color	USB, Network
HP DeskJet 3059a E-all-in-one Printer j611n	Color	USB, Network
HP Designjet t790ps 44in	Color	USB, Network
HP Designjet t790ps 24in	Color	USB, Network
HP Designjet t1300 Postscript	Color	USB, Network
HP LaserJet Professional m1214nfh Multifunction Printer	Mono	USB; Network
HP LaserJet Professional cp1522n	Color	USB, Network
HP Designjet t2300 Postscript	Color	USB, Network
HP LaserJet Professional cp1527nw	Color	USB, Network
HP OfficeJet Pro 8000 Enterprise a811a	Color	USB, Network
HP LaserJet Professional cp1526nw	Color	USB, Network
HP LaserJet Professional cp1528nw	Color	USB, Network
HP Designjet 4000ps	Color	USB, Network
HP OfficeJet 100 Mobile l411	Color	USB
HP LaserJet Professional cp1523n	Color	USB, Network
HP LaserJet Professional cp1525nw	Color	USB, Network
HP LaserJet Professional cp1525nw	Color	USB, Network
HP LaserJet Professional cp1521n	Color	USB, Network
HP LaserJet Professional cp1525n	Color	USB, Network
HP Designjet z6200ps 60in Photo	Color	USB, Network
HP Designjet t7100ps	Color	USB, Network
HP Designjet t7100 Monochrome	Mono	USB; Network
HP Designjet z6100ps 42in Photo	Color	USB, Network
HP Designjet z6200ps 42in Photo	Color	USB, Network
HP Designjet z6100ps 60in Photo	Color	USB, Network
HP LaserJet Professional cm1418fnw	Color	USB, Network
HP LaserJet m1536dnf MFP	Mono	USB; Network
HP LaserJet Professional cm1413fn	Color	USB, Network
HP DeskJet Ink Adv 2060 k110	Color	USB
HP LaserJet Professional cm1415fn	Color	USB, Network
HP LaserJet Professional cm1411fn	Color	USB, Network
HP LaserJet Professional cm1412fn	Color	USB, Network
HP LaserJet Professional cm1417fnw	Color	USB, Network
HP OfficeJet 6500 e710	Color	USB, Network
HP PhotoSmart Ink Adv k510	Color	USB, Network
HP LaserJet Pro cp1025nw Color Printer Series	Color	USB, Network
HP Color LaserJet cp5520 Series Printer	Color	USB, Network
HP LaserJet Professional cm1415fnw	Color	USB, Network
HP LaserJet Professional cm1415fnw	Color	USB, Network
HP LaserJet Professional cm1416fnw	Color	USB, Network

HP DeskJet Ink Adv 2010 k010	Color	USB
HP LaserJet Pro cp1025 Color Printer Series	Color	USB
HP LaserJet Professional m1213nf Multifunction Printer	Mono	USB; Network
HP OfficeJet Pro 8500a Plus E-aio Printer - a910g	Color	USB, Network
HP LaserJet Professional m1217nfw Multifunction Printer	Mono	USB; Network
HP PhotoSmart Estn c510 Series	Color	USB, Network
HP OfficeJet 7500 e910	Color	USB, Network
HP Designjet t1100 44-in Postscript Printer	Color	USB, Network
HP OfficeJet Pro 8500a Premium E-aio Printer - a910n	Color	USB, Network
HP PhotoSmart Prem c410 Series	Color	USB, Network
HP Designjet t1100 24-in Postscript Printer	Color	USB, Network
HP DeskJet 2000 j210 Series	Color	USB
HP Designjet t1120 24-in Postscript Printer	Color	USB, Network
HP PhotoSmart Prem c310 Series	Color	USB, Network
HP PhotoSmart Plus b210 Series	Color	USB, Network
HP Designjet 4500ps	Color	USB, Network
HP Designjet t1120 44-in Postscript Printer	Color	USB, Network
HP DeskJet 1000 j110 Series	Color	USB
HP DeskJet 3050 j610 Series	Color	USB, Network
HP DeskJet 3000 j310 Series	Color	USB, Network
HP Designjet t770 24-in Postscript Printer	Color	USB, Network
HP OfficeJet 6500 e710n-z	Color	USB, Network
HP Envy 100 d410 Series	Color	USB, Network
HP OfficeJet 4500 g510n-z All-in-one Printer	Color	USB, Network
HP DeskJet 2050 j510 All-in-one Printer	Color	USB
HP DeskJet 1050 j410 All-in-one Printer	Color	USB
HP DeskJet 1051 All-in-one Printer	Color	USB
HP LaserJet Professional m1136 Multifunction Printer	Mono	USB
HP DeskJet 1055 All-in-one Printer -j410e	Color	USB
HP PhotoSmart Wireless All-in-one Printer - b110	Color	USB, Network
HP PhotoSmart All-in-one Printer - b010	Color	USB
HP DeskJet 1056 All-in-one Printer -j410a	Color	USB
HP OfficeJet 4500 All-in-one Printer - k710	Color	USB, Network
HP LaserJet Professional m1212nf Multifunction Printer	Mono	USB; Network
HP LaserJet Professional m1132 Multifunction Printer	Mono	USB
HP LaserJet Professional p1102s Printer	Mono	USB
HP LaserJet Professional p1102 Printer	Mono	USB
HP OfficeJet 4400 k410 All-in-one Printer	Color	USB
HP LaserJet Professional p1606dn Printer	Mono	USB; Network
HP LaserJet Professional p1102w Printer	Mono	USB; Network
HP OfficeJet 4000 k210 Printer	Color	USB
HP PhotoSmart d110 Series Printer	Color	USB, Network
HP LaserJet Professional m1132s Multifunction Printer	Mono	USB

HP LaserJet Professional p1566	Mono	USB
HP OfficeJet 4500 All-in-one Printer - g510g	Color	USB, Network
HP OfficeJet 4500 All-in-one Printer - g510h	Color	USB, Network
HP OfficeJet 4500 Desktop All-in-one Printer - g510a	Color	USB, Network
HP OfficeJet 4500 All-in-one Desktop Printer - g510b	Color	USB, Network
HP Color LaserJet cp5225dn	Color	USB, Network
HP Color LaserJet cp5225dn	Color	USB, Network
HP Color LaserJet cp4520 Series Printer	Color	USB, Network
HP Color LaserJet cp5225n	Color	USB, Network
HP Color LaserJet cp5225n	Color	USB, Network
HP Designjet t1200 Postscript	Color	USB, Network
HP Color LaserJet cp4020 Series Printer	Color	USB, Network
HP Designjet t770 Postscript	Color	USB, Network
HP Color LaserJet cp5225	Color	USB
HP DeskJet f2476 All-in-one Printer	Color	USB
HP DeskJet f2440 All-in-one Printer	Color	USB
HP DeskJet f2493 All-in-one Printer	Color	USB
HP PhotoSmart a640 Printer Series	Color	USB
HP DeskJet f2420 All-in-one Printer	Color	USB
HP DeskJet f2488 All-in-one Printer	Color	USB
HP DeskJet f2430 All-in-one Printer	Color	USB
HP DeskJet f4500 All-in-one Printer Series	Color	USB, Network
HP PhotoSmart Wireless All-in-one Printer - b109q	Color	USB, Network
HP PhotoSmart Premium Fax All-in-one Printer Series - c309c	Color	USB, Network
HP PhotoSmart Premium Fax All-in-one Printer Series - c309a	Color	USB, Network
HP PhotoSmart Wireless All-in-one Printer - b109n	Color	USB, Network
HP PhotoSmart Wireless All-in-one Printer - b109q=r	Color	USB, Network
HP PhotoSmart Wireless All-in-one Printer - b109q=r	Color	USB, Network
HP DeskJet f2480 All-in-one Printer	Color	USB
HP DeskJet f2483 All-in-one Printer	Color	USB
HP PhotoSmart All-in-one Printer - b109d	Color	USB
HP PhotoSmart All-in-one Printer - b109e	Color	USB
HP PhotoSmart All-in-one Printer - b109c	Color	USB
HP DeskJet f2423 All-in-one Printer	Color	USB
HP DeskJet f2410 All-in-one Printer	Color	USB
HP DeskJet f2418 All-in-one Printer	Color	USB
HP PhotoSmart All-in-one Printer - b109a	Color	USB
HP PhotoSmart Premium All-in-one Printer Series - c309h	Color	USB, Network
HP DeskJet f2492 All-in-one Printer	Color	USB
HP PhotoSmart Premium All-in-one Printer Series - c309g	Color	USB, Network
HP DeskJet d1660 Printer	Color	USB
HP DeskJet d5545 Printer	Color	USB, Network
HP DeskJet d1663 Printer	Color	USB

HP PhotoSmart Plus All-in-one Printer - b209a	Color	USB, Network
HP PhotoSmart Plus All-in-one Printer - b209b	Color	USB, Network
HP PhotoSmart Plus All-in-one Printer - b209c	Color	USB, Network
HP PhotoSmart c4795 All-in-one Printer	Color	USB, Network
HP DeskJet d1630 Printer	Color	USB
HP PhotoSmart c4793 All-in-one Printer	Color	USB, Network
HP DeskJet Ink Advantage k209a All-in-one Printer	Color	USB
HP DeskJet d5560 Printer	Color	USB, Network
HP DeskJet d5568 Printer	Color	USB, Network
HP PhotoSmart c4785 All-in-one Printer	Color	USB, Network
HP DeskJet d5563 Printer	Color	USB, Network
HP DeskJet Ink Advantage k109a Printer	Color	USB
HP DeskJet d1650 Printer	Color	USB
HP PhotoSmart c4740 All-in-one Printer	Color	USB, Network
HP LaserJet p3015 Printer	Mono	USB; Network
HP DeskJet d1620 Printer	Color	USB
HP LaserJet p3011 Printer	Mono	USB; Network
HP PhotoSmart c4799 All-in-one Printer	Color	USB, Network
HP PhotoSmart c4750 All-in-one Printer	Color	USB, Network
HP PhotoSmart c4783 All-in-one Printer	Color	USB, Network
HP DeskJet d1668 Printer	Color	USB
HP PhotoSmart c4788 All-in-one Printer	Color	USB, Network
HP OfficeJet 7000 Wide Format Printer -- e809a	Color	USB, Network
HP PhotoSmart c4798 All-in-one Printer	Color	USB, Network
HP DeskJet d1658 Printer	Color	USB
HP PhotoSmart c4780 All-in-one Printer	Color	USB, Network
HP DeskJet f4480 All-in-one Printer	Color	USB
HP OfficeJet 6000 Printer - e609a	Color	USB, Network
HP DeskJet d2680 Printer	Color	USB
HP PhotoSmart c4688 All-in-one Printer	Color	USB
HP DeskJet f4488 All-in-one Printer	Color	USB
HP DeskJet f4435 All-in-one Printer	Color	USB
HP DeskJet f4473 All-in-one Printer	Color	USB
HP DeskJet f4450 All-in-one Printer	Color	USB
HP DeskJet f4483 All-in-one Printer	Color	USB
HP DeskJet f4492 All-in-one Printer	Color	USB
HP DeskJet d2645 Printer	Color	USB
HP DeskJet f4440 All-in-one Printer	Color	USB
HP DeskJet d2668 Printer	Color	USB
HP PhotoSmart c4640 All-in-one Printer	Color	USB
HP DeskJet d2666 Printer	Color	USB
HP PhotoSmart c4683 All-in-one Printer	Color	USB
HP OfficeJet 6000 Wireless Printer - e609n	Color	USB, Network

HP PhotoSmart c4650 All-in-one Printer	Color	USB
HP DeskJet d2663 Printer	Color	USB
HP DeskJet d2660 Printer	Color	USB
HP PhotoSmart c4670 All-in-one Printer	Color	USB
HP LaserJet m9059 MFP	Mono	USB; Network
HP Color LaserJet cm6049 MFP	Color	USB, Network
HP DeskJet f4470 All-in-one Printer	Color	USB
HP PhotoSmart c4673 All-in-one Printer	Color	USB
HP PhotoSmart c4680 All-in-one Printer	Color	USB
HP DeskJet f4472 All-in-one Printer	Color	USB
HP PhotoSmart c4610 All-in-one Printer	Color	USB
HP PhotoSmart c4635 All-in-one Printer	Color	USB
HP OfficeJet 6500 Wireless All-in-one Printer - e709q	Color	USB, Network
HP Designjet 4020ps	Color	USB, Network
HP OfficeJet 6500 Wireless All-in-one Printer - e709n	Color	USB, Network
HP Designjet 4520ps	Color	USB, Network
HP OfficeJet 6500 All-in-one Printer - e709c	Color	USB, Network
HP OfficeJet 6500 All-in-one Printer - e709a	Color	USB, Network
HP LaserJet p1009 Printer	Mono	USB
HP OfficeJet Pro 8500 Premier All-in-one Printer - a909n	Color	USB, Network
HP Color LaserJet cp1215 Printer	Color	USB, Network
HP Color LaserJet 1600 Printer	Color	USB, Network
HP OfficeJet Pro 8500 Wireless All-in-one Printer - a909g	Color	USB, Network
HP OfficeJet Pro 8500 All-in-one Printer - a909a	Color	USB, Network
HP Color LaserJet 2600n Printer	Color	USB, Network
HP PhotoSmart Premium Fax All-in-one Printer - c309a	Color	USB, Network
HP OfficeJet Pro 8000 Wireless Printer - a809n	Color	USB, Network
HP OfficeJet Pro 8000 Printer - a809a	Color	USB, Network
HP Color LaserJet cp1514n Printer	Color	USB, Network
HP PhotoSmart d7560 Printer	Color	USB
HP PhotoSmart c4540 All-in-one Printer	Color	USB, Network
HP Color LaserJet cp2025x Printer	Color	USB, Network
HP Color LaserJet cm1017 Multifunction Printer	Color	USB, Network
HP OfficeJet j4660 All-in-one Printer	Color	USB, Network
HP OfficeJet j4680c All-in-one Printer	Color	USB, Network
HP LaserJet p2055 Printer	Mono	USB
HP OfficeJet j4680 All-in-one Printer	Color	USB, Network
HP PhotoSmart c4593 All-in-one Printer	Color	USB, Network
HP Color LaserJet cp2025 Printer	Color	USB, Network
HP Color LaserJet cp2025n Printer	Color	USB, Network
HP PhotoSmart c6350 All-in-one Printer	Color	USB, Network
HP LaserJet p2055d Printer	Mono	USB
HP PhotoSmart c5373 All-in-one Printer	Color	USB

HP PhotoSmart c5393 All-in-one Printer	Color	USB
HP PhotoSmart b8550 Photo Printer	Color	USB
HP PhotoSmart c4599 All-in-one Printer	Color	USB, Network
HP DeskJet f4210 All-in-one Printer	Color	USB
HP LaserJet m2727nfs Multifunction Printer	Mono	USB; Network
HP Color LaserJet cm2320fxi Multifunction Printer	Color	USB, Network
HP PhotoSmart c5390 All-in-one Printer	Color	USB
HP LaserJet m1522n Multifunction Printer	Mono	USB; Network
HP PhotoSmart c6324 All-in-one Printer	Color	USB, Network
HP PhotoSmart c5388 All-in-one Printer	Color	USB
HP Color LaserJet cm1312 Multifunction Printer	Color	USB
HP PhotoSmart c4550 All-in-one Printer	Color	USB, Network
HP PhotoSmart c5380 All-in-one Printer	Color	USB
HP PhotoSmart c6388 All-in-one Printer	Color	USB, Network
HP Color LaserJet cp3525x Printer	Color	USB, Network
HP LaserJet p2055dn Printer	Mono	USB; Network
HP PhotoSmart c4583 All-in-one Printer	Color	USB, Network
HP PhotoSmart b8558 Photo Printer	Color	USB
HP Color LaserJet cm3530fs Multifunction Printer	Color	USB, Network
HP LaserJet p2035n Printer	Mono	USB
HP PhotoSmart c4585 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6340 All-in-one Printer	Color	USB, Network
HP PhotoSmart c4580 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6383 All-in-one Printer	Color	USB, Network
HP Color LaserJet cm2320n Multifunction Printer	Color	USB, Network
HP LaserJet p2035 Printer	Mono	USB
HP PhotoSmart c6375 All-in-one Printer	Color	USB, Network
HP DeskJet f4280 All-in-one	Color	USB
HP LaserJet m1522nf Multifunction Printer	Mono	USB; Network
HP PhotoSmart c6380 All-in-one Printer	Color	USB, Network
HP PhotoSmart c5370 All-in-one Printer	Color	USB
HP Color LaserJet cp3525 Printer	Color	USB, Network
HP PhotoSmart c4570 All-in-one Printer	Color	USB, Network
HP PhotoSmart c4572 All-in-one Printer	Color	USB, Network
HP Color LaserJet cm1015 Multifunction Printer	Color	USB, Network
HP PhotoSmart c4588 All-in-one Printer	Color	USB, Network
HP DeskJet f4213 All-in-one Printer	Color	USB
HP PhotoSmart c5383 All-in-one Printer	Color	USB
HP LaserJet m2727nf Multifunction Printer	Mono	USB; Network
HP Color LaserJet cp2025dn Printer	Color	USB, Network
HP PhotoSmart b8553 Photo Printer	Color	USB
HP Color LaserJet cp3525dn Printer	Color	USB, Network
HP LaserJet m2727 Multifunction Printer	Mono	USB; Network

HP PhotoSmart c4575 All-in-one Printer	Color	USB, Network
HP Color LaserJet cm2320nf Multifunction Printer	Color	USB, Network
HP Color LaserJet cp3525n Printer	Color	USB, Network
HP Color LaserJet cm2320 Multifunction Printer	Color	USB, Network
HP LaserJet m1522 Multifunction Printer	Mono	USB; Network
HP Color LaserJet cm1312nfi Multifunction Printer	Color	USB, Network
HP PhotoSmart c4573 All-in-one Printer	Color	USB, Network
HP LaserJet p2055x Printer	Mono	USB
HP Color LaserJet cm3530 Multifunction Printer	Color	USB, Network
HP PhotoSmart a637 Compact Photo Printer	Color	USB
HP LaserJet m1005 Multifunction Printer	Mono	USB
HP LaserJet m1319f Multifunction Printer	Mono	USB
HP LaserJet m1120 Multifunction Printer	Mono	USB
HP LaserJet m1120n Multifunction Printer	Mono	USB; Network
HP PhotoSmart a636 Compact Photo Printer	Color	USB
HP PhotoSmart a538 Compact Photo Printer	Color	USB
HP DeskJet f735 All-in-one Printer	Color	USB
HP DeskJet d730 Printer	Color	USB
HP PhotoSmart a536 Compact Photo Printer	Color	USB
HP PhotoSmart c5550 All-in-one Printer	Color	USB, Network
HP PhotoSmart a532 Compact Photo Printer	Color	USB
HP PhotoSmart c5540 All-in-one Printer	Color	USB, Network
HP PhotoSmart c5570 All-in-one Printer	Color	USB, Network
HP PhotoSmart c5580 All-in-one Printer	Color	USB, Network
HP OfficeJet j4535 All-in-one Printer	Color	USB, Network
HP OfficeJet j4580c All-in-one Printer	Color	USB, Network
HP OfficeJet j4560 All-in-one Printer	Color	USB, Network
HP OfficeJet j4585 All-in-one Printer	Color	USB, Network
HP OfficeJet j4540 All-in-one Printer	Color	USB, Network
HP Color LaserJet cm6030 Multifunction Printer	Color	USB, Network
HP Color LaserJet cm6030f Multifunction Printer	Color	USB, Network
HP OfficeJet j4525 All-in-one Printer	Color	USB, Network
HP OfficeJet j4550 All-in-one Printer	Color	USB, Network
HP PhotoSmart d5463 Printer	Color	USB
HP PhotoSmart d5460 Printer	Color	USB
HP OfficeJet j4580 All-in-one Printer	Color	USB, Network
HP LaserJet p1008 Printer	Mono	USB
HP LaserJet p1007 Printer	Mono	USB
HP PhotoSmart d5468 Printer	Color	USB
HP OfficeJet j4524 All-in-one Printer	Color	USB, Network
HP PhotoSmart c4486 All-in-one Printer	Color	USB
HP DeskJet f4293 All-in-one Printer	Color	USB
HP Color LaserJet cm6049f Multifunction Printer	Color	USB, Network

HP DeskJet f4274 All-in-one Printer	Color	USB
HP LaserJet p4015 Printer	Mono	USB; Network
HP Color LaserJet cm6040 Multifunction Printer	Color	USB, Network
HP DeskJet d2545 Printer	Color	USB
HP DeskJet f4273 All-in-one Printer	Color	USB
HP LaserJet p4014n Printer	Mono	USB; Network
HP DeskJet d2530 Printer	Color	USB
HP DeskJet f4283 All-in-one Printer	Color	USB
HP LaserJet p4515 Printer	Mono	USB; Network
HP DeskJet f4224 All-in-one Printer	Color	USB
HP LaserJet p4515n Printer	Mono	USB; Network
HP LaserJet p4015dn Printer	Mono	USB; Network
HP PhotoSmart c4450 All-in-one Printer	Color	USB
HP Color LaserJet cp6015de Printer	Color	USB, Network
HP Color LaserJet cp6015dn Printer	Color	USB, Network
HP Color LaserJet cp1515n Printer	Color	USB, Network
HP DeskJet d2568 Printer	Color	USB
HP DeskJet f4294 All-in-one Printer	Color	USB
HP DeskJet d2566 Printer	Color	USB
HP DeskJet f4240 All-in-one Printer	Color	USB
HP PhotoSmart c4473 All-in-one Printer	Color	USB
HP DeskJet f4292 All-in-one Printer	Color	USB
HP LaserJet p4015tn Printer	Mono	USB; Network
HP DeskJet d2560 Printer	Color	USB
HP DeskJet f4288 All-in-one Printer	Color	USB
HP PhotoSmart c4410 All-in-one Printer	Color	USB
HP LaserJet p4014 Printer	Mono	USB; Network
HP PhotoSmart c4490 All-in-one Printer	Color	USB
HP LaserJet m9059 Multifunction Printer	Mono	USB; Network
HP PhotoSmart c4480 All-in-one Printer	Color	USB
HP PhotoSmart c4472 All-in-one Printer	Color	USB
HP DeskJet f4238 All-in-one Printer	Color	USB
HP DeskJet d2563 Printer	Color	USB
HP PhotoSmart c4494 All-in-one Printer	Color	USB
HP DeskJet f4250 All-in-one Printer	Color	USB
HP LaserJet m9050 Multifunction Printer	Mono	USB; Network
HP PhotoSmart c4470 All-in-one Printer	Color	USB
HP Color LaserJet cp6015n Printer	Color	USB, Network
HP PhotoSmart c4493 All-in-one Printer	Color	USB
HP DeskJet f4280 All-in-one Printer	Color	USB
HP DeskJet f4280 All-in-one Printer	Color	USB
HP Color LaserJet cm6040f Multifunction Printer	Color	USB, Network
HP DeskJet f4235 All-in-one Printer	Color	USB

HP DeskJet f4272 All-in-one Printer	Color	USB
HP LaserJet p4015n Printer	Mono	USB; Network
HP Color LaserJet cp6015x Printer	Color	USB, Network
HP Color LaserJet cp6015xh Printer	Color	USB, Network
HP LaserJet p4515tn Printer	Mono	USB; Network
HP DeskJet f4230 All-in-one Printer	Color	USB
HP LaserJet m9040 Multifunction Printer	Mono	USB; Network
HP PhotoSmart c4440 All-in-one Printer	Color	USB
HP DeskJet f4275 All-in-one Printer	Color	USB
HP LaserJet p4515xm Printer	Mono	USB; Network
HP Color LaserJet cp1518ni Printer	Color	USB, Network
HP LaserJet p4015x Printer	Mono	USB; Network
HP PhotoSmart c4483 All-in-one Printer	Color	USB
HP PhotoSmart c4424 All-in-one Printer	Color	USB
HP LaserJet p4515x Printer	Mono	USB; Network
HP PhotoSmart c4485 All-in-one Printer	Color	USB
HP PhotoSmart c4435 All-in-one Printer	Color	USB
HP PhotoSmart c4488 All-in-one Printer	Color	USB
HP LaserJet p4014dn Printer	Mono	USB; Network
HP PhotoSmart c4343 All-in-one Printer	Color	USB
HP PhotoSmart c4340 All-in-one Printer	Color	USB
HP OfficeJet j6480 All-in-one Printer	Color	USB, Network
HP PhotoSmart c4348 All-in-one Printer	Color	USB
HP PhotoSmart Pro b8850 Printer	Color	USB
HP OfficeJet j6405 All-in-one Printer	Color	USB, Network
HP PhotoSmart c4345 All-in-one Printer	Color	USB
HP OfficeJet j6415 All-in-one Printer	Color	USB, Network
HP OfficeJet j6410 All-in-one Printer	Color	USB, Network
HP OfficeJet j6413 All-in-one Printer	Color	USB, Network
HP OfficeJet Pro l7480 All-in-one Printer	Color	USB
HP OfficeJet j6450 All-in-one Printer	Color	USB, Network
HP PhotoSmart c4342 All-in-one Printer	Color	USB
HP OfficeJet j6488 All-in-one Printer	Color	USB, Network
HP PhotoSmart c4344 All-in-one Printer	Color	USB
HP OfficeJet j6424 All-in-one Printer	Color	USB, Network
HP OfficeJet h470wf Mobile Printer	Color	USB, Network
HP LaserJet p1505 Printer	Mono	USB
HP OfficeJet h470bt Mobile Printer	Color	USB, Network
HP OfficeJet h470wbt Mobile Printer	Color	USB, Network
HP OfficeJet h470 Mobile Printer	Color	USB, Network
HP LaserJet p1005 Printer	Mono	USB
HP LaserJet p1006 Printer	Mono	USB
HP LaserJet p1505n Printer	Mono	USB; Network

HP LaserJet 5200lx Printer	Mono	USB; Network
HP LaserJet 1005 Printer	Mono	USB
HP LaserJet 1000 Printer	Mono	USB
HP Color LaserJet 3500dtn Printer	Color	USB
HP Color LaserJet 3600 Printer	Color	USB, Network
HP LaserJet 1020 Printer	Mono	USB
HP Color LaserJet 3500 Printer	Color	USB
HP LaserJet 1022 Printer	Mono	USB; Network
HP Color LaserJet 3600n Printer	Color	USB, Network
HP PhotoSmart c4384 All-in-one Printer	Color	USB, Network
HP LaserJet 1022n Printer	Mono	USB; Network
HP LaserJet 1018 Printer	Mono	USB
HP LaserJet 1020 Plus Printer	Mono	USB
HP LaserJet 1022nxi Printer	Mono	USB; Network
HP PhotoSmart c4380 All-in-one Printer	Color	USB, Network
HP LaserJet 1018s Printer	Mono	USB
HP OfficeJet Pro k8600 Color Printer	Color	USB, Network
HP Color LaserJet 3500n Printer	Color	USB
HP PhotoSmart c4385 All-in-one Printer	Color	USB, Network
HP LaserJet 1022nw Printer	Mono	USB; Network
HP Color LaserJet 3550n Printer	Color	USB
HP Color LaserJet 3500dn Printer	Color	USB
HP Color LaserJet 3600dn Printer	Color	USB, Network
HP PhotoSmart c4388 All-in-one Printer	Color	USB, Network
HP Color LaserJet 3550 Printer	Color	USB
HP PhotoSmart c4383 All-in-one Printer	Color	USB, Network
HP OfficeJet Pro k8600dn Color Printer	Color	USB, Network
HP PhotoSmart c7280 All-in-one Printer	Color	USB, Network
HP PhotoSmart c7250 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6245 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6268 All-in-one Printer	Color	USB, Network
HP PhotoSmart d7463 Printer	Color	USB, Network
HP PhotoSmart c6280 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6288 All-in-one Printer	Color	USB, Network
HP PhotoSmart d7268 Printer	Color	USB, Network
HP PhotoSmart c6270 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6285 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6275 All-in-one Printer	Color	USB, Network
HP PhotoSmart c7288 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6263 All-in-one Printer	Color	USB, Network
HP PhotoSmart d5345 Printer	Color	USB, Network
HP PhotoSmart c6240 All-in-one Printer	Color	USB, Network
HP PhotoSmart d7263 Printer	Color	USB, Network

HP PhotoSmart c8180 All-in-one Printer	Color	USB, Network
HP PhotoSmart d7460 Printer	Color	USB, Network
HP PhotoSmart c7275 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6283 All-in-one Printer	Color	USB, Network
HP OfficeJet k7103 Printer	Color	USB
HP PhotoSmart d7260 Printer	Color	USB, Network
HP PhotoSmart d7255 Printer	Color	USB, Network
HP PhotoSmart d5368 Printer	Color	USB, Network
HP PhotoSmart d7245 Printer	Color	USB, Network
HP OfficeJet k7100 Printer	Color	USB
HP PhotoSmart d7468 Printer	Color	USB, Network
HP PhotoSmart c7283 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6286 All-in-one Printer	Color	USB, Network
HP PhotoSmart c8188 All-in-one Printer	Color	USB, Network
HP OfficeJet k7108 Printer	Color	USB
HP PhotoSmart c6260 All-in-one Printer	Color	USB, Network
HP PhotoSmart c8183 All-in-one Printer	Color	USB, Network
HP PhotoSmart d5360 Printer	Color	USB, Network
HP PhotoSmart c8150 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6250 All-in-one Printer	Color	USB, Network
HP PhotoSmart d5363 Printer	Color	USB, Network
HP PhotoSmart a526 Compact Photo Printer	Color	USB
HP PhotoSmart a525 Compact Photo Printer	Color	USB
HP PhotoSmart a522xi Compact Photo Printer	Color	USB
HP PhotoSmart a826 Home Photo Center	Color	USB
HP PhotoSmart a620 Compact Photo Printer	Color	USB
HP PhotoSmart a627 Compact Photo Printer	Color	USB
HP PhotoSmart a828 Home Photo Center	Color	USB
HP PhotoSmart a827 Home Photo Center	Color	USB
HP PhotoSmart a622 Compact Photo Printer	Color	USB
HP PhotoSmart a628 Compact Photo Printer	Color	USB
HP PhotoSmart a626 Compact Photo Printer	Color	USB
HP PhotoSmart a528 Compact Photo Printer	Color	USB
HP PhotoSmart a522 Compact Photo Printer	Color	USB
HP PhotoSmart c5290 All-in-one Printer	Color	USB, Network
HP PhotoSmart c4205 All-in-one Printer	Color	USB
HP PhotoSmart c4275 All-in-one Printer	Color	USB
HP LaserJet p2014 Printer	Mono	USB
HP Color LaserJet cp3505x Printer	Color	USB, Network
HP PhotoSmart c4280 All-in-one Printer	Color	USB
HP PhotoSmart c4272 All-in-one Printer	Color	USB
HP PhotoSmart a446 Compact Photo Printer	Color	USB
HP PhotoSmart c4210 All-in-one Printer	Color	USB

HP PhotoSmart a321 Compact Photo Printer	Color	USB
HP PhotoSmart c4285 All-in-one Printer	Color	USB
HP PhotoSmart c5283 All-in-one Printer	Color	USB, Network
HP PhotoSmart c4270 All-in-one Printer	Color	USB
HP PhotoSmart c5270 All-in-one Printer	Color	USB, Network
HP PhotoSmart c4250 All-in-one Printer	Color	USB
HP Color LaserJet cp3505dn Printer	Color	USB, Network
HP PhotoSmart c4293 All-in-one Printer	Color	USB
HP PhotoSmart a442 Compact Photo Printer	Color	USB
HP PhotoSmart c4288 All-in-one Printer	Color	USB
HP PhotoSmart c4273 All-in-one Printer	Color	USB
HP PhotoSmart c5288 All-in-one Printer	Color	USB, Network
HP Color LaserJet cp3505 Printer	Color	USB, Network
HP PhotoSmart c5240 All-in-one Printer	Color	USB, Network
HP PhotoSmart c4240 All-in-one Printer	Color	USB
HP PhotoSmart c5293 All-in-one Printer	Color	USB, Network
HP PhotoSmart c4283 All-in-one Printer	Color	USB
HP PhotoSmart c5280 All-in-one Printer	Color	USB, Network
HP PhotoSmart c5250 All-in-one Printer	Color	USB, Network
HP Color LaserJet cp3505n Printer	Color	USB, Network
HP PhotoSmart c4294 All-in-one Printer	Color	USB
HP PhotoSmart c5273 All-in-one Printer	Color	USB, Network
HP PhotoSmart c4235 All-in-one Printer	Color	USB
HP PhotoSmart c5275 All-in-one Printer	Color	USB, Network
HP LaserJet p2014n Printer	Mono	USB
HP PhotoSmart a440 Compact Photo Printer	Color	USB
HP PhotoSmart a320 Compact Photo Printer	Color	USB
HP OfficeJet Pro I7550 All-in-one Printer	Color	USB, Network
HP OfficeJet Pro I7780 All-in-one Printer	Color	USB, Network
HP OfficeJet Pro I7500 Series All-in-one Printer	Color	USB, Network
HP OfficeJet Pro I7710 All-in-one Printer	Color	USB, Network
HP OfficeJet j5735 All-in-one Printer	Color	USB
HP OfficeJet Pro I7590 All-in-one Printer	Color	USB, Network
HP OfficeJet j5730 All-in-one Printer	Color	USB
HP OfficeJet Pro I7600 Series All-in-one Printer	Color	USB, Network
HP OfficeJet Pro I7680 All-in-one Printer	Color	USB, Network
HP OfficeJet j5725 All-in-one Printer	Color	USB
HP OfficeJet j5783 All-in-one Printer	Color	USB
HP OfficeJet Pro I7300 Series All-in-one Printer	Color	USB, Network
HP OfficeJet Pro k5300 Printer	Color	USB, Network
HP OfficeJet Pro I7580 All-in-one Printer	Color	USB, Network
HP OfficeJet Pro I7700 Series All-in-one Printer	Color	USB, Network
HP OfficeJet j5780 All-in-one Printer	Color	USB

HP OfficeJet Pro I7750 All-in-one Printer	Color	USB, Network
HP OfficeJet j5785 All-in-one Printer	Color	USB
HP OfficeJet j5790 All-in-one Printer	Color	USB
HP OfficeJet Pro k5400dtn Printer	Color	USB, Network
HP OfficeJet Pro k5400z Printer	Color	USB, Network
HP OfficeJet Pro I7380 All-in-one Printer	Color	USB, Network
HP OfficeJet j5738 All-in-one Printer	Color	USB
HP OfficeJet j5740 All-in-one Printer	Color	USB
HP OfficeJet Pro k5400dn Printer	Color	USB, Network
HP OfficeJet Pro I7555 All-in-one Printer	Color	USB, Network
HP OfficeJet j5750 All-in-one Printer	Color	USB
HP OfficeJet j5788 All-in-one Printer	Color	USB
HP OfficeJet Pro I7650 All-in-one Printer	Color	USB, Network
HP OfficeJet Pro k5400n Printer	Color	USB, Network
HP OfficeJet Pro k5400 Printer	Color	USB, Network
HP OfficeJet Pro I7681 All-in-one Printer	Color	USB, Network
HP LaserJet m5025 Multifunction Printer	Color	USB, Network
HP LaserJet m3027x Multifunction Printer	Mono	USB; Network
HP Color LaserJet cp4005dn Printer	Color	USB, Network
HP LaserJet m3027 Multifunction Printer	Mono	USB; Network
HP Color LaserJet cp4005 Series Printer	Color	USB, Network
HP Color LaserJet cp4005n Printer	Color	USB, Network
HP LaserJet p2015x Printer	Mono	USB; Network
HP LaserJet p3005 Printer	Mono	USB; Network
HP LaserJet p3004 Printer	Mono	USB; Network
HP LaserJet p3005dn Printer	Mono	USB; Network
HP LaserJet p2015d Printer	Mono	USB; Network
HP LaserJet p2015 Printer	Mono	USB
HP Color LaserJet 2700 Printer	Color	USB, Network
HP LaserJet p2015n Printer	Mono	USB; Network
HP LaserJet p3005d Printer	Mono	USB; Network
HP LaserJet p3005n Printer	Mono	USB; Network
HP Color LaserJet 2700n Printer	Color	USB, Network
HP LaserJet p3005x Printer	Mono	USB; Network
HP LaserJet p3005dtn Printer	Mono	USB; Network
HP LaserJet p2015dn Printer	Mono	USB; Network
HP PhotoSmart c7180 All-in-one Printer	Color	USB, Network
HP PhotoSmart c7188 All-in-one Printer	Color	USB, Network
HP PhotoSmart c7185 All-in-one Printer	Color	USB, Network
HP PhotoSmart d5069 Printer	Color	USB
HP PhotoSmart Pro b8338 Printer	Color	USB
HP PhotoSmart d5065 Printer	Color	USB
HP PhotoSmart d5063 Printer	Color	USB

HP PhotoSmart c6170 All-in-one Printer	Color	USB, Network
HP PhotoSmart c7150 All-in-one Printer	Color	USB, Network
HP PhotoSmart a316 Compact Photo Printer	Color	USB
HP PhotoSmart a310 Compact Photo Printer	Color	USB
HP PhotoSmart d5156 Printer	Color	USB
HP PhotoSmart a311 Compact Photo Printer	Color	USB
HP PhotoSmart c6154 All-in-one Printer	Color	USB, Network
HP PhotoSmart c7170 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6185 All-in-one Printer	Color	USB, Network
HP PhotoSmart d5060 Printer	Color	USB
HP PhotoSmart d5145 Printer	Color	USB
HP PhotoSmart c6150 All-in-one Printer	Color	USB, Network
HP PhotoSmart d5155 Printer	Color	USB
HP PhotoSmart Pro b8350 Printer	Color	USB
HP PhotoSmart c5185 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6183 All-in-one Printer	Color	USB, Network
HP PhotoSmart c5170 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6188 All-in-one Printer	Color	USB, Network
HP PhotoSmart d5168 Printer	Color	USB
HP PhotoSmart Pro b8330 Printer	Color	USB
HP PhotoSmart c5150 All-in-one Printer	Color	USB, Network
HP PhotoSmart c7154 All-in-one Printer	Color	USB, Network
HP PhotoSmart c5175 All-in-one Printer	Color	USB, Network
HP PhotoSmart c5188 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6180 All-in-one Printer	Color	USB, Network
HP PhotoSmart c7183 All-in-one Printer	Color	USB, Network
HP PhotoSmart a314 Compact Photo Printer	Color	USB
HP PhotoSmart c5140 All-in-one Printer	Color	USB, Network
HP PhotoSmart c5183 All-in-one Printer	Color	USB, Network
HP PhotoSmart c7190 All-in-one Printer	Color	USB, Network
HP PhotoSmart d5163 Printer	Color	USB
HP PhotoSmart c5194 All-in-one Printer	Color	USB, Network
HP PhotoSmart Pro b8353 Printer	Color	USB
HP PhotoSmart c5180 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6190 All-in-one Printer	Color	USB, Network
HP PhotoSmart d5160 Printer	Color	USB
HP PhotoSmart c5173 All-in-one Printer	Color	USB, Network
HP PhotoSmart c6175 All-in-one Printer	Color	USB, Network
HP PhotoSmart d7163 Printer	Color	USB
HP PhotoSmart d7168 Printer	Color	USB
HP PhotoSmart d7155 Printer	Color	USB
HP PhotoSmart d7160 Printer	Color	USB
HP PhotoSmart d7145 Printer	Color	USB

HP PhotoSmart d6160 Printer	Color	USB
HP PhotoSmart d6163 Printer	Color	USB
HP PhotoSmart d6168 Printer	Color	USB
HP PhotoSmart c4180 All-in-one Printer	Color	USB
HP PhotoSmart a712 Compact Photo Printer	Color	USB
HP PhotoSmart c3170 All-in-one Printer	Color	USB
HP PhotoSmart c3193 All-in-one Printer	Color	USB
HP PhotoSmart d7363 Printer	Color	USB, Network
HP PhotoSmart c4193 All-in-one Printer	Color	USB
HP PhotoSmart c3194 All-in-one Printer	Color	USB
HP PhotoSmart c4140 All-in-one Printer	Color	USB
HP PhotoSmart c4150 All-in-one Printer	Color	USB
HP PhotoSmart a618 Compact Photo Printer	Color	USB
HP PhotoSmart c3183 All-in-one Printer	Color	USB
HP PhotoSmart a510 Compact Photo Printer	Color	USB
HP PhotoSmart a616 Compact Photo Printer	Color	USB
HP PhotoSmart c4110 All-in-one Printer	Color	USB
HP PhotoSmart c4183 All-in-one Printer	Color	USB
HP PhotoSmart c3140 All-in-one Printer	Color	USB
HP PhotoSmart c3125 All-in-one Printer	Color	USB
HP PhotoSmart c3135 All-in-one Printer	Color	USB
HP PhotoSmart d7345 Printer	Color	USB, Network
HP PhotoSmart a512 Compact Photo Printer	Color	USB
HP PhotoSmart c4188 All-in-one Printer	Color	USB
HP PhotoSmart a617 Compact Photo Printer	Color	USB
HP PhotoSmart d7355 Printer	Color	USB, Network
HP PhotoSmart c3188 All-in-one Printer	Color	USB
HP PhotoSmart c3150 All-in-one Printer	Color	USB
HP PhotoSmart c4194 All-in-one Printer	Color	USB
HP PhotoSmart a432 Compact Photo Printer	Color	USB
HP PhotoSmart a516 Compact Photo Printer	Color	USB
HP PhotoSmart c3173 All-in-one Printer	Color	USB
HP PhotoSmart c3175 All-in-one Printer	Color	USB
HP PhotoSmart c4173 All-in-one Printer	Color	USB
HP PhotoSmart a434 Compact Photo Printer	Color	USB
HP PhotoSmart c4175 All-in-one Printer	Color	USB
HP PhotoSmart a436 Compact Photo Printer	Color	USB
HP PhotoSmart a433 Compact Photo Printer	Color	USB
HP PhotoSmart c3110 All-in-one Printer	Color	USB
HP PhotoSmart a612 Compact Photo Printer	Color	USB
HP PhotoSmart c4170 All-in-one Printer	Color	USB
HP PhotoSmart c4190 All-in-one Printer	Color	USB
HP PhotoSmart c3190 All-in-one Printer	Color	USB

HP PhotoSmart a610 Compact Photo Printer	Color	USB
HP PhotoSmart a430 Compact Photo Printer	Color	USB
HP PhotoSmart c3180 All-in-one Printer	Color	USB
HP PhotoSmart a716 Compact Photo Printer	Color	USB
HP PhotoSmart a717 Compact Photo Printer	Color	USB
HP PhotoSmart d7360 Printer	Color	USB, Network
HP PhotoSmart d7368 Printer	Color	USB, Network
HP OfficeJet 6318 All-in-one Printer	Color	USB, Network
HP Color LaserJet 2605dn Xi Printer	Color	USB, Network
HP LaserJet 5200 Printer	Mono	USB; Network
HP Color LaserJet 2605dn Printer	Color	USB, Network
HP OfficeJet 6307 All-in-one Printer	Color	USB, Network
HP OfficeJet 6308 All-in-one Printer	Color	USB, Network
HP OfficeJet 6305 All-in-one Printer	Color	USB, Network
HP OfficeJet 6301 All-in-one Printer	Color	USB, Network
HP Color LaserJet 2605dtn Printer	Color	USB, Network
HP LaserJet 5200l Printer	Mono	USB; Network
HP OfficeJet 6313 All-in-one Printer	Color	USB, Network
HP OfficeJet 6315 All-in-one Printer	Color	USB, Network
HP Color LaserJet 2605 Printer	Color	USB, Network
HP LaserJet 5200n Printer	Mono	USB; Network
HP LaserJet 5200tn Printer	Mono	USB; Network
HP OfficeJet 6304 All-in-one Printer	Color	USB, Network
HP OfficeJet 6310v All-in-one Printer	Color	USB, Network
HP OfficeJet 6310xi All-in-one Printer	Color	USB, Network
HP OfficeJet 6310 All-in-one Printer	Color	USB, Network
HP LaserJet 5200dtn Printer	Mono	USB; Network
HP LaserJet 3050z All-in-one Printer	Mono	USB; Network
HP LaserJet 3050 All-in-one Printer	Mono	USB; Network
HP LaserJet 3392 All-in-one Printer	Mono	USB; Network
HP DeskJet 6980xi Printer	Color	USB, Network
HP LaserJet 3390 All-in-one Printer	Mono	USB; Network
HP DeskJet 6988 Printer	Color	USB, Network
HP LaserJet 3055 All-in-one Printer	Mono	USB; Network
HP DeskJet 6983 Printer	Color	USB, Network
HP DeskJet 6988xi Printer	Color	USB, Network
HP DeskJet 6940 Printer	Color	USB, Network
HP DeskJet 6980dt Printer	Color	USB, Network
HP DeskJet 6988dt Printer	Color	USB, Network
HP DeskJet 6940dt Printer	Color	USB, Network
HP LaserJet 3052 All-in-one Printer	Mono	USB; Network
HP DeskJet 6980 Printer	Color	USB, Network
HP DeskJet 6943 Printer	Color	USB, Network

HP Color LaserJet 3800dn Printer	Color	USB, Network
HP Color LaserJet 3800n Printer	Color	USB, Network
HP Color LaserJet 3000 Printer	Color	USB, Network
HP Color LaserJet 3800dtn Printer	Color	USB, Network
HP Color LaserJet 3800 Printer	Color	USB, Network
HP Color LaserJet 3000dtn Printer	Color	USB, Network
HP Color LaserJet 3000dn Printer	Color	USB, Network
HP Color LaserJet 3000n Printer	Color	USB, Network
HP OfficeJet Pro k850 Printer	Color	USB, Network
HP OfficeJet Pro k550 Printer	Color	USB, Network
HP OfficeJet Pro k550xi Printer	Color	USB, Network
HP OfficeJet Pro k850dn Printer	Color	USB, Network
HP DeskJet 460wf Mobile Printer	Color	USB
HP DeskJet 460cb Mobile Printer	Color	USB
HP DeskJet 460c Mobile Printer	Color	USB
HP DeskJet 460wbt Mobile Printer	Color	USB
HP OfficeJet Pro k550dtn Printer	Color	USB, Network
HP OfficeJet Pro k550dtwn Printer	Color	USB, Network
HP DeskJet 6620xi Color Inkjet Printer	Color	USB, Network
HP LaserJet 4300dtnsl Printer	Mono	USB; Network
HP DeskJet 3822 Color Inkjet Printer	Color	USB
HP PSC 2105 All-in-one Printer	Color	USB
HP DeskJet 1600cn Printer	Color	USB
HP OfficeJet 7130 All-in-one Printer	Color	USB, Network
HP PhotoSmart 2575xi All-in-one Printer	Color	USB, Network
HP PhotoSmart 245xi Compact Photo Printer	Color	USB
HP Color LaserJet 5 Printer	Color	USB
HP PhotoSmart 325v Compact Photo Printer	Color	USB
HP Color Inkjet cp1700 Printer	Color	USB, Network
HP OfficeJet 7215 All-in-one Printer	Color	USB, Network
HP Business Inkjet 2250 Printer	Color	USB
HP PhotoSmart 130v Printer	Color	USB
HP PSC 2358 All-in-one Printer	Color	USB
HP DeskJet 9300 Printer	Color	USB
HP Business Inkjet 1200dtn Printer	Color	USB
HP DeskJet 5440v Photo Printer	Color	USB
HP DeskJet 990cm Printer	Color	USB
HP PSC 760 All-in-one Printer	Color	USB
HP LaserJet 4250tn Printer	Mono	USB; Network
HP LaserJet 5si Mx Printer	Mono	USB
HP DeskJet 990cxi Printer	Color	USB
HP PhotoSmart 8038 Printer	Color	USB
HP PhotoSmart 1115 Printer	Color	USB, Network

HP DeskJet 640c Pavilion Turbo Printer	Color	USB
HP LaserJet 410dtn Printer	Mono	USB
HP DeskJet 990cse Printer	Color	USB
HP DeskJet 5700 Color Inkjet Printer	Color	USB
HP DeskJet 9808 Printer	Color	USB
HP PSC 2170 All-in-one Printer	Color	USB
HP PhotoSmart 8750 Professional Photo Printer	Color	USB, Network
HP LaserJet 8000 Series Printer	Mono	USB
HP PhotoSmart 8050v Printer	Color	USB
HP DeskJet 5443 Photo Printer	Color	USB
HP Color LaserJet 2830 All-in-one Printer	Color	USB, Network
HP Mopier 320 Printer	Mono	USB
HP DeskJet 5440 Photo Printer	Color	USB
HP PhotoSmart 7550 Printer	Color	USB
HP Color LaserJet 9500n Printer	Color	USB, Network
HP LaserJet 1320tn Printer	Mono	USB; Network
HP Color LaserJet 4550n Printer	Color	USB, Network
HP Color Inkjet cp1160tn Printer	Color	USB
HP OfficeJet d145xi All-in-one Printer	Color	USB, Network
HP PhotoSmart 7550v Printer	Color	USB
HP OfficeJet 7410 All-in-one Printer	Color	USB, Network
HP DeskJet 845cvr Printer	Color	USB
HP PhotoSmart 2615 All-in-one Printer	Color	USB, Network
HP DeskJet 950c Printer	Color	USB
HP PSC 720 All-in-one Printer	Color	USB
HP LaserJet 1300n Printer	Mono	USB; Network
HP DeskJet 6543d Color Inkjet Printer	Color	USB
HP Color LaserJet 4700dtn Printer	Color	USB, Network
HP LaserJet 1320nw Printer	Mono	USB; Network
HP PhotoSmart 8050 Printer	Color	USB
HP Color Inkjet cp1700d Printer	Color	USB, Network
HP LaserJet 4300dtn Printer	Mono	USB; Network
HP DeskJet 825cvr Printer	Color	USB
HP DeskJet 656c Printer	Color	USB
HP Color LaserJet 2500 Printer	Color	USB
HP OfficeJet 7210v All-in-one Printer	Color	USB, Network
HP PhotoSmart 2610 All-in-one Printer	Color	USB, Network
HP DeskJet 970cxi Printer	Color	USB
HP DeskJet 3816 Color Inkjet Printer	Color	USB
HP DeskJet 6548 Color Inkjet Printer	Color	USB
HP Color LaserJet 5550hdn Printer	Color	USB, Network
HP LaserJet 1160 Series Printer	Mono	USB
HP PhotoSmart 7459 Photo Printer	Color	USB

HP PhotoSmart 3210a All-in-one Printer	Color	USB, Network
HP Color LaserJet 4600dtn Printer	Color	USB
HP LaserJet 4100n Printer	Mono	USB
HP PhotoSmart 325xi Compact Photo Printer	Color	USB
HP PSC 2350 All-in-one Printer	Color	USB
HP LaserJet 8150dn Printer	Mono	USB
HP DeskJet 970cse Printer	Color	USB
HP OfficeJet v40xi All-in-one Printer	Color	USB
HP Color LaserJet 5500hdn Printer	Color	USB
HP Color LaserJet 8550mn Printer	Color	USB
HP PSC 2210 All-in-one Printer	Color	USB
HP DeskJet 5442 Photo Printer	Color	USB
HP PhotoSmart 1315 Printer	Color	USB
HP PSC 1613 All-in-one Printer	Color	USB
HP PhotoSmart 145v Compact Photo Printer	Color	USB
HP OfficeJet d125xi All-in-one Printer	Color	USB, Network
HP Color LaserJet 4550hdn Plus Printer	Color	USB, Network
HP PSC 2175v All-in-one Printer	Color	USB
HP LaserJet 4200l Printer	Mono	USB; Network
HP DeskJet 1220cse Printer	Color	USB
HP Business Inkjet 1200dtn Printer	Color	USB
HP PhotoSmart 8150v Photo Printer	Color	USB
HP LaserJet 5000le Printer	Mono	USB; Network
HP PhotoSmart 7960 Photo Printer	Color	USB, Network
HP PSC 1615 All-in-one Printer	Color	USB
HP LaserJet 4350dtn Printer	Mono	USB; Network
HP OfficeJet 7140xi All-in-one Printer	Color	USB, Network
HP LaserJet 4300tn Printer	Mono	USB; Network
HP Color LaserJet 8550mfp-dlvry/unpkging	Color	USB
HP LaserJet 1160 Printer	Mono	USB
HP LaserJet 3300 Multifunction Printer	Mono	USB
HP DeskJet 980cxi Printer	Color	USB
HP DeskJet 960cxi Printer	Color	USB
HP Color LaserJet 2500n Printer	Color	USB
HP PSC 2510xi PhotoSmart All-in-one Printer	Color	USB, Network
HP LaserJet 9040dn Printer	Mono	USB; Network
HP Color LaserJet 8550gn Printer	Color	USB
HP Color LaserJet 2500lse Printer	Color	USB
HP LaserJet 5si Mopier Engine	Mono	USB
HP LaserJet 5si Mopier Engine	Mono	USB
HP PhotoSmart p1100 Printer	Color	USB
HP LaserJet 2410 Printer	Mono	USB; Network
HP Business Inkjet 1100 Printer	Color	USB

HP PhotoSmart 375b Compact Photo Printer With Battery	Color	USB
HP OfficeJet 6213 All-in-one Printer	Color	USB
HP DeskJet 1220c/ps Printer	Color	USB
HP Color LaserJet 4550n Plus Printer	Color	USB, Network
HP PSC 2150 All-in-one Printer	Color	USB
HP DeskJet 6500 Color Inkjet Printer	Color	USB
HP DeskJet 6543 Color Inkjet Printer	Color	USB
HP OfficeJet 5110xi All-in-one Printer	Color	USB
HP DeskJet 5943 Photo Printer	Color	USB
HP OfficeJet 6210 All-in-one Printer	Color	USB
HP PhotoSmart 2713 All-in-one Printer	Color	USB, Network
HP LaserJet 2100se Printer	Mono	USB; Network
HP PSC 2210xi All-in-one Printer	Color	USB
HP LaserJet 2200 Printer	Mono	USB; Network
HP OfficeJet 6215 All-in-one Printer	Color	USB
HP OfficeJet 7213 All-in-one Printer	Color	USB, Network
HP DeskJet 5438 Photo Printer	Color	USB
HP PSC 1510v All-in-one Printer	Color	USB
HP PhotoSmart p1000/1000 Printer	Color	USB
HP OfficeJet 7408 All-in-one Printer	Color	USB, Network
HP DeskJet 450wbt Mobile Printer	Color	USB
HP PSC 2355v All-in-one Printer	Color	USB
HP LaserJet 5si Printer	Mono	USB
HP OfficeJet 7410xi All-in-one Printer	Color	USB, Network
HP Color LaserJet 3700d Printer	Color	USB, Network
HP PSC 1610 All-in-one Printer	Color	USB
HP DeskJet 5800 Color Inkjet Printer	Color	USB, Network
HP PhotoSmart 385xi Compact Photo Printer	Color	USB
HP PSC 1605 All-in-one Printer	Color	USB
HP OfficeJet 6203 All-in-one Printer	Color	USB
HP OfficeJet d155xi All-in-one Printer	Color	USB, Network
HP Color LaserJet 5500dn Printer	Color	USB
HP DeskJet 916c Printer	Color	USB
HP DeskJet 6628 Color Inkjet Printer	Color	USB, Network
HP DeskJet 9800d Printer	Color	USB
HP DeskJet 5652 Color Inkjet Printer	Color	USB
HP DeskJet 3819 Color Inkjet Printer	Color	USB
HP PhotoSmart 8253 Printer	Color	USB
HP Color LaserJet 8500 Printer	Color	USB
HP DeskJet 9670 Printer	Color	USB
HP LaserJet 8000n Printer	Mono	USB; Network
HP PhotoSmart 3110v All-in-one Printer	Color	USB
HP LaserJet 3320n Multifunction Printer	Mono	USB

HP LaserJet 4250dtn Printer	Mono	USB; Network
HP DeskJet 640c Lite Printer	Color	USB
HP PhotoSmart 3310xi All-in-one Printer	Color	USB, Network
HP PSC 750xi All-in-one Printer	Color	USB
HP Business Inkjet 3000dtn Printer	Color	USB, Network
HP LaserJet 1300xi Printer	Mono	USB; Network
HP DeskJet 648c Printer	Color	USB
HP DeskJet 995c Printer	Color	USB
HP Color LaserJet 4550hdn Printer	Color	USB, Network
HP Business Inkjet 3000n Printer	Color	USB, Network
HP DeskJet 955c Printer	Color	USB
HP DeskJet 3810 Color Inkjet Printer	Color	USB
HP LaserJet 4350n Printer	Mono	USB; Network
HP LaserJet 8000dn Printer	Mono	USB; Network
HP DeskJet 6840dt Color Inkjet Printer	Color	USB, Network
HP DeskJet 640c Printer	Color	USB
HP Mopier 240 Printer	Mono	USB
HP DeskJet 630c Printer	Color	USB
HP DeskJet 9803d Printer	Color	USB
HP DeskJet 5850w Color Inkjet Printer	Color	USB, Network
HP LaserJet 4350 Printer	Mono	USB; Network
HP Color LaserJet 4650hdn Printer	Color	USB, Network
HP PSC 1610xi All-in-one Printer	Color	USB
HP Color LaserJet 5500dtn Printer	Color	USB
HP Color LaserJet 2840 All-in-one Printer	Color	USB, Network
HP PhotoSmart 2570 All-in-one Printer	Color	USB, Network
HP PhotoSmart 2608 All-in-one Printer	Color	USB, Network
HP Color LaserJet 2550 Printer	Color	USB, Network
HP Color LaserJet 2820 All-in-one Printer	Color	USB, Network
HP Color Inkjet cp1160 Printer	Color	USB
HP LaserJet 9000 Printer	Mono	USB; Network
HP LaserJet 3380 All-in-one Printer	Mono	USB
HP PhotoSmart 7850 Printer	Color	USB
HP DeskJet 1280 Printer	Color	USB
HP Color LaserJet 5500 Printer	Color	USB
HP Color LaserJet 8500dn Printer	Color	USB
HP DeskJet 5550 Color Inkjet Printer	Color	USB
HP LaserJet 1220se All-in-one Printer	Mono	USB
HP PhotoSmart 130xi Printer	Color	USB
HP Color LaserJet 9500gp Printer	Color	USB, Network
HP PhotoSmart 3110 All-in-one Printer	Color	USB
HP LaserJet 5si Hm Printer	Mono	USB
HP PhotoSmart 8750gp Professional Photo Printer	Color	USB, Network

HP LaserJet 4200In Printer	Mono	USB; Network
HP DeskJet 6540dt Color Inkjet Printer	Color	USB
HP DeskJet 6843 Color Inkjet Printer	Color	USB, Network
HP PSC 2352 All-in-one Printer	Color	USB
HP PSC 2175 All-in-one Printer	Color	USB
HP LaserJet 4200dtn Printer	Mono	USB; Network
HP DeskJet 5743 Color Inkjet Printer	Color	USB
HP PhotoSmart 7960gp Photo Printer	Color	USB, Network
HP DeskJet 5650 Color Inkjet Printer	Color	USB
HP PhotoSmart 7450v Photo Printer	Color	USB
HP PhotoSmart 425 Compact Photo Printer	Color	USB
HP DeskJet 5440xi Photo Printer	Color	USB
HP LaserJet 4050 Printer	Mono	USB
HP OfficeJet k80 All-in-one Printer	Color	USB
HP Color LaserJet 4700 Printer	Color	USB, Network
HP PhotoSmart 145xi Compact Photo Printer	Color	USB
HP DeskJet 5168 Color Inkjet Printer	Color	USB
HP OfficeJet v40 All-in-one Printer	Color	USB
HP LaserJet 3015 All-in-one Printer	Mono	USB
HP PSC 1510s All-in-one Printer	Color	USB
HP PhotoSmart 2610xi All-in-one Printer	Color	USB, Network
HP Business Inkjet 1100dtn Printer	Color	USB
HP LaserJet 4250n Printer	Mono	USB; Network
HP DeskJet 6830v Color Inkjet Printer	Color	USB, Network
HP Color LaserJet 3700dn Printer	Color	USB, Network
HP LaserJet 8150n Printer	Mono	USB
HP DeskJet 5850 Color Inkjet Printer	Color	USB, Network
HP Color LaserJet 4700ph+ Printer	Color	USB, Network
HP PhotoSmart 2605 All-in-one Printer	Color	USB, Network
HP PSC 2510 PhotoSmart All-in-one Printer	Color	USB, Network
HP OfficeJet 7115 All-in-one Printer	Color	USB, Network
HP PhotoSmart 428xi Compact Photo Printer	Color	USB
HP DeskJet 960cse Printer	Color	USB
HP PhotoSmart 7260 Photo Printer	Color	USB
HP DeskJet 5650w Color Inkjet Printer	Color	USB
HP PhotoSmart 7458 Photo Printer	Color	USB
HP PhotoSmart 7260w Photo Printer	Color	USB
HP DeskJet 940cw Printer	Color	USB
HP PhotoSmart 425v Compact Photo Printer	Color	USB
HP LaserJet 2200d Printer	Mono	USB; Network
HP DeskJet 920cxi Printer	Color	USB
HP Color LaserJet 5550n Printer	Color	USB, Network
HP Color LaserJet 4500dn Printer	Color	USB, Network

HP Color LaserJet 4500n Printer	Color	USB, Network
HP PSC 1513s All-in-one Printer	Color	USB
HP LaserJet 4300n Printer	Mono	USB; Network
HP LaserJet 8000 Printer	Mono	USB; Network
HP DeskJet 975cse Printer	Color	USB
HP OfficeJet 7110 All-in-one Printer	Color	USB, Network
HP OfficeJet g85 All-in-one Printer	Color	USB, Network
HP LaserJet 5100se Printer	Mono	USB
HP PhotoSmart 7960w Photo Printer	Color	USB, Network
HP PhotoSmart 7755 Photo Printer	Color	USB
HP LaserJet 5000 Series Printer	Mono	USB
HP Color Inkjet cp1700ps Printer	Color	USB, Network
HP PhotoSmart 8450xi Photo Printer	Color	USB, Network
HP LaserJet 1015 Printer	Mono	USB
HP PhotoSmart 3314 All-in-one Printer	Color	USB, Network
HP LaserJet 9050dn Printer	Mono	USB; Network
HP OfficeJet g95 All-in-one Printer	Color	USB, Network
HP DeskJet 1220cxi Printer	Color	USB
HP OfficeJet k60xi All-in-one Printer	Color	USB
HP LaserJet 2100 Series Printer	Mono	USB
HP DeskJet 6127 Color Inkjet Printer	Color	USB, Network
HP DeskJet 6623 Color Inkjet Printer	Color	USB, Network
HP DeskJet 9860 Printer	Color	USB
HP DeskJet 995ck Color Inkjet Printer	Color	USB
HP PhotoSmart 375bxi Compact Photo Printer With Battery	Color	USB
HP PSC 900 All-in-one Printer	Color	USB
HP Business Inkjet 2800dtn Printer	Color	USB, Network
HP DeskJet 5938 Photo Printer	Color	USB
HP DeskJet 6600 Series Color Inkjet Printer	Color	USB, Network
HP PSC 1603 All-in-one Printer	Color	USB
HP LaserJet 4350dtnsl Printer	Mono	USB; Network
HP Color LaserJet 5m Printer	Color	USB
HP PSC 2550 PhotoSmart All-in-one Printer	Color	USB, Network
HP PhotoSmart 7830 Printer	Color	USB
HP PhotoSmart 8450 Photo Printer	Color	USB, Network
HP LaserJet 8100 Printer	Mono	USB
HP PhotoSmart 1215vm Printer	Color	USB
HP Color LaserJet 4700n Printer	Color	USB, Network
HP DeskJet 5740xi Color Inkjet Printer	Color	USB
HP DeskJet 5150w Color Inkjet Printer	Color	USB
HP PhotoSmart 8150xi Photo Printer	Color	USB
HP PhotoSmart 385 Compact Photo Printer	Color	USB
HP LaserJet 2300dtn Printer	Mono	USB; Network

HP PhotoSmart 7450 Photo Printer	Color	USB
HP LaserJet 2300 Series Printer	Mono	USB; Network
HP DeskJet 957c Printer	Color	USB
HP DeskJet 6540 Color Inkjet Printer	Color	USB
HP LaserJet 4300dtns Printer	Mono	USB; Network
HP Business Inkjet 2280 Printer	Color	USB
HP DeskJet 5145 Color Inkjet Printer	Color	USB
HP PSC 2179 All-in-one Printer	Color	USB
HP Business Inkjet 1100d Printer	Color	USB
HP DeskJet 6800 Color Inkjet Printer	Color	USB, Network
HP LaserJet 9050 Printer	Mono	USB; Network
HP PhotoSmart 8450v Photo Printer	Color	USB, Network
HP PhotoSmart 8153 Photo Printer	Color	USB
HP LaserJet 8150 Printer	Mono	USB
HP PSC 2355p All-in-one Printer	Color	USB
HP LaserJet 5100le Printer	Mono	USB
HP LaserJet 2420n Printer	Mono	USB; Network
HP Color LaserJet 4550dn Printer	Color	USB, Network
HP Color LaserJet 4610n Printer	Color	USB, Network
HP PhotoSmart 7838 Printer	Color	USB
HP DeskJet 5151 Color Inkjet Printer	Color	USB
HP LaserJet 4250 Printer	Mono	USB; Network
HP LaserJet 9050n Printer	Mono	USB; Network
HP DeskJet 5432 Photo Printer	Color	USB
HP LaserJet 3320 Multifunction Printer	Mono	USB
HP PhotoSmart 420 Compact Photo Printer	Color	USB
HP Color LaserJet 8500n Printer	Color	USB
HP PhotoSmart 7260v Photo Printer	Color	USB
HP DeskJet 450cbi Mobile Printer	Color	USB
HP OfficeJet k60 All-in-one Printer	Color	USB
HP DeskJet 995ck Printer	Color	USB
HP PhotoSmart 145 Compact Photo Printer	Color	USB
HP DeskJet 640u Printer	Color	USB
HP Business Inkjet 1200dn Printer	Color	USB
HP DeskJet 5100 Color Inkjet Printer	Color	USB
HP DeskJet 895cse Printer	Color	USB
HP LaserJet 1320 Printer	Mono	USB; Network
HP LaserJet 9040n Printer	Mono	USB; Network
HP DeskJet 5940xi Photo Printer	Color	USB
HP Color LaserJet 3700n Printer	Color	USB, Network
HP PhotoSmart 8458 Photo Printer	Color	USB, Network
HP DeskJet 6620 Color Inkjet Printer	Color	USB, Network
HP PSC 2310 All-in-one Printer	Color	USB, Network

HP PhotoSmart 8750xi Professional Photo Printer	Color	USB, Network
HP PSC 1514 All-in-one Printer	Color	USB
HP LaserJet 9000hns Printer	Mono	USB; Network
HP OfficeJet g55 All-in-one Printer	Color	USB, Network
HP PhotoSmart 475v Compact Photo Printer	Color	USB
HP PSC 2500 PhotoSmart All-in-one Printer	Color	USB, Network
HP LaserJet 2200dtn Printer	Mono	USB; Network
HP PhotoSmart 7850vxi Printer	Color	USB
HP PSC 2210v All-in-one Printer	Color	USB
HP LaserJet 2430 Printer	Mono	USB; Network
HP Business Inkjet 2800 Printer	Color	USB, Network
HP PhotoSmart 2575v All-in-one Printer	Color	USB, Network
HP Color LaserJet 4600 Printer	Color	USB
HP LaserJet 9000hnf Printer	Mono	USB; Network
HP DeskJet 5600 Color Inkjet Printer	Color	USB
HP LaserJet 1010 Printer	Mono	USB
HP PhotoSmart 130 Printer	Color	USB
HP OfficeJet g85xi All-in-one Printer	Color	USB, Network
HP PSC 2355xi All-in-one Printer	Color	USB
HP PhotoSmart 422 Compact Photo Printer	Color	USB
HP LaserJet 2200dse Printer	Mono	USB; Network
HP PhotoSmart 3108 All-in-one Printer	Color	USB
HP PhotoSmart 8758 Professional Photo Printer	Color	USB, Network
HP OfficeJet 9120 All-in-one Printer	Color	USB, Network
HP LaserJet 4240n Printer	Mono	USB; Network
HP LaserJet 2420 Printer	Mono	USB; Network
HP DeskJet 1600c Printer	Color	USB
HP OfficeJet d135 All-in-one Printer	Color	USB, Network
HP PSC 2357 All-in-one Printer	Color	USB
HP PhotoSmart 7150v Printer	Color	USB
HP DeskJet 930c Printer	Color	USB
HP DeskJet 975cxi Printer	Color	USB
HP PhotoSmart 7960v Photo Printer	Color	USB, Network
HP Color LaserJet 2500l Printer	Color	USB
HP DeskJet 934c Printer	Color	USB
HP LaserJet 2100 Printer	Mono	USB; Network
HP OfficeJet g55xi All-in-one Printer	Color	USB, Network
HP LaserJet 2300d Printer	Mono	USB; Network
HP LaserJet 5100dtn Printer	Mono	USB
HP Business Inkjet 2250tn Printer	Color	USB
HP PhotoSmart 370 Compact Photo Printer	Color	USB
HP LaserJet 1320t Printer	Mono	USB; Network
HP PhotoSmart 7660 Photo Printer	Color	USB

HP LaserJet 2300n Printer	Mono	USB; Network
HP LaserJet 3020 All-in-one Printer	Mono	USB
HP DeskJet 6520xi Color Inkjet Printer	Color	USB
HP LaserJet 2200dt Printer	Mono	USB; Network
HP PSC 2171 All-in-one Printer	Color	USB
HP DeskJet 3820v Color Inkjet Printer	Color	USB
HP OfficeJet k80xi All-in-one Printer	Color	USB
HP PhotoSmart 8453 Photo Printer	Color	USB, Network
HP PSC 2108 All-in-one Printer	Color	USB
HP PhotoSmart 2613 All-in-one Printer	Color	USB, Network
HP Color LaserJet 5550dtn Printer	Color	USB, Network
HP PhotoSmart 338 Compact Photo Printer	Color	USB
HP LaserJet 4250dtnsl Printer	Mono	USB; Network
HP PhotoSmart 2574 All-in-one Printer	Color	USB, Network
HP PhotoSmart 428v Compact Photo Printer	Color	USB
HP PSC 1510xi All-in-one Printer	Color	USB
HP PhotoSmart 8230 Printer	Color	USB
HP PhotoSmart 3310 All-in-one Printer	Color	USB, Network
HP PhotoSmart 7760od Photo Printer	Color	USB
HP PSC 2110 All-in-one Printer	Color	USB
HP PhotoSmart 8238 Printer	Color	USB
HP PhotoSmart 2578 All-in-one Printer	Color	USB, Network
HP PhotoSmart 7350 Printer	Color	USB
HP OfficeJet v40s All-in-one Printer	Color	USB
HP Business Inkjet 2230 Printer	Color	USB
HP PSC 2175xi All-in-one Printer	Color	USB
HP Color LaserJet 4600hdn Printer	Color	USB
HP LaserJet 1012 Printer	Mono	USB
HP DeskJet 5551 Color Inkjet Printer	Color	USB
HP Color LaserJet 3700 Printer	Color	USB, Network
HP OfficeJet 5100 All-in-one Printer	Color	USB
HP LaserJet 4200lvn Printer	Mono	USB; Network
HP PhotoSmart 8053 Printer	Color	USB
HP PSC 2353p All-in-one Printer	Color	USB
HP PhotoSmart 385v Compact Photo Printer	Color	USB
HP PSC 780 All-in-one Printer	Color	USB
HP LaserJet 2100tn Printer	Mono	USB; Network
HP OfficeJet 5105 All-in-one Printer	Color	USB
HP LaserJet 2100xi Printer	Mono	USB; Network
HP Color LaserJet 9500 Printer	Color	USB, Network
HP Color LaserJet 4650 Printer	Color	USB, Network
HP PhotoSmart 475 Compact Photo Printer	Color	USB
HP PhotoSmart 100 Printer	Color	USB

HP PhotoSmart 3210 All-in-one Printer	Color	USB, Network
HP LaserJet 3310 Digital Printer Copier	Mono	USB
HP Color LaserJet 9500hdn Printer	Color	USB, Network
HP PSC 1510 All-in-one Printer	Color	USB
HP Business Inkjet 1200d Printer	Color	USB
HP DeskJet 632c Printer	Color	USB
HP OfficeJet 7100 All-in-one Printer	Color	USB, Network
HP PhotoSmart 7150 Printer	Color	USB
HP DeskJet 920cvr Printer	Color	USB
HP DeskJet 940cvr Printer	Color	USB
HP Business Inkjet 2300 Printer	Color	USB, Network
HP LaserJet 3330 Multifunction Printer	Mono	USB
HP PhotoSmart p1000xi Printer	Color	USB
HP DeskJet 960c Printer	Color	USB
HP PhotoSmart 7762w Photo Printer	Color	USB
HP PhotoSmart 1218xi Printer	Color	USB
HP Business Inkjet 2280tn Printer	Color	USB
HP DeskJet 6850 Color Inkjet Printer	Color	USB, Network
HP PhotoSmart 2610v All-in-one Printer	Color	USB, Network
HP PhotoSmart 245 Compact Photo Printer	Color	USB
HP DeskJet 5150 Color Inkjet Printer	Color	USB
HP DeskJet 948c Printer	Color	USB
HP Business Inkjet 1000 Printer	Color	USB
HP Business Inkjet 1000 Printer	Color	USB
HP PSC 2200 All-in-one Printer	Color	USB
HP OfficeJet 6110 All-in-one Printer	Color	USB
HP OfficeJet d135xi All-in-one Printer	Color	USB, Network
HP LaserJet 5100 Printer	Mono	USB
HP PhotoSmart 3210xi All-in-one Printer	Color	USB, Network
HP Business Inkjet 3000 Printer	Color	USB, Network
HP DeskJet 920cw Printer	Color	USB
HP PhotoSmart 3207 All-in-one Printer	Color	USB, Network
HP DeskJet 5550w Color Inkjet Printer	Color	USB
HP LaserJet 4050n Printer	Mono	USB
HP Color LaserJet 3700dtn Printer	Color	USB, Network
HP PSC 950vr All-in-one Printer	Color	USB
HP Color LaserJet 2550In Printer	Color	USB, Network
HP PSC 750 All-in-one Printer	Color	USB
HP LaserJet 9000n Printer	Mono	USB; Network
HP LaserJet 4200dtns Printer	Mono	USB; Network
HP LaserJet 1320 Series Printer	Mono	USB; Network
HP PhotoSmart 240 Compact Photo Printer	Color	USB
HP Color LaserJet 4550 Printer	Color	USB, Network

HP DeskJet 6840xi Color Inkjet Printer	Color	USB, Network
HP PSC 2115 All-in-one Printer	Color	USB
HP LaserJet 4200tn Printer	Mono	USB; Network
HP DeskJet 3870 Color Inkjet Printer	Color	USB
HP DeskJet 6848 Color Inkjet Printer	Color	USB, Network
HP DeskJet 5748 Color Inkjet Printer	Color	USB
HP DeskJet 895cxi Printer	Color	USB
HP OfficeJet 9110 All-in-one Printer	Color	USB, Network
HP PhotoSmart 3214 All-in-one Printer	Color	USB, Network
HP PSC 2353 All-in-one Printer	Color	USB
HP PSC 2110v All-in-one Printer	Color	USB
HP PhotoSmart 7655 Photo Printer	Color	USB
HP DeskJet 3820 Color Inkjet Printer	Color	USB
HP PhotoSmart 230 Printer	Color	USB
HP PhotoSmart 3210v All-in-one Printer	Color	USB, Network
HP PSC 1608 All-in-one Printer	Color	USB
HP OfficeJet 7210xi All-in-one Printer	Color	USB, Network
HP PhotoSmart 8158 Photo Printer	Color	USB
HP DeskJet 920c Printer	Color	USB
HP PSC 1513 All-in-one Printer	Color	USB
HP OfficeJet 7310xi All-in-one Printer	Color	USB, Network
HP PhotoSmart 428 Compact Photo Printer	Color	USB
HP PhotoSmart 330 Series Compact Photo Printer	Color	USB
HP Business Inkjet 2300dtn Printer	Color	USB, Network
HP PhotoSmart 8450gp Photo Printer	Color	USB, Network
HP OfficeJet 7313 All-in-one Printer	Color	USB, Network
HP DeskJet 350c Printer	Color	USB
HP LaserJet 4050t Printer	Mono	USB
HP LaserJet 2300dn Printer	Mono	USB; Network
HP DeskJet 940c Printer	Color	USB
HP Color LaserJet 4650dn Printer	Color	USB, Network
HP PhotoSmart 1218 Printer	Color	USB
HP PhotoSmart 2710 All-in-one Printer	Color	USB, Network
HP PSC 1610v All-in-one Printer	Color	USB
HP Color LaserJet 4650n Printer	Color	USB, Network
HP PhotoSmart 475xi Compact Photo Printer	Color	USB
HP PhotoSmart 8250xi Printer	Color	USB
HP PhotoSmart 422v Compact Photo Printer	Color	USB
HP Business Inkjet 2300n Printer	Color	USB, Network
HP LaserJet 5000gn Printer	Mono	USB; Network
HP DeskJet 932c Printer	Color	USB
HP PhotoSmart 7350w Printer	Color	USB
HP OfficeJet 7210 All-in-one Printer	Color	USB, Network

HP Color LaserJet 2500tn Printer	Color	USB
HP OfficeJet 7130xi All-in-one Printer	Color	USB, Network
HP LaserJet 4050se Printer	Mono	USB
HP OfficeJet 6150 All-in-one Printer	Color	USB
HP LaserJet 1300t Printer	Mono	USB; Network
HP LaserJet 5000n Printer	Mono	USB; Network
HP PhotoSmart 8030 Printer	Color	USB
HP PSC 950 All-in-one Printer	Color	USB
HP OfficeJet 6200 All-in-one Printer	Color	USB
HP PSC 1508 All-in-one Printer	Color	USB
HP DeskJet 895c Printer	Color	USB
HP OfficeJet 6210xi All-in-one Printer	Color	USB
HP PhotoSmart 2573 All-in-one Printer	Color	USB, Network
HP PhotoSmart 337 Compact Photo Printer	Color	USB
HP LaserJet 4050tn Printer	Mono	USB
HP PSC 2355 All-in-one Printer	Color	USB
HP PSC 1507 All-in-one Printer	Color	USB
HP OfficeJet 7208 All-in-one Printer	Color	USB, Network
HP PhotoSmart 2571 All-in-one Printer	Color	USB, Network
HP LaserJet 8100dn Printer	Mono	USB
HP LaserJet 4240 Printer	Mono	USB; Network
HP LaserJet 2430dtn Printer	Mono	USB; Network
HP PhotoSmart 230v Printer	Color	USB
HP DeskJet 5550v Color Inkjet Printer	Color	USB
HP PhotoSmart 8753 Professional Photo Printer	Color	USB, Network
HP LaserJet 8150hn Printer	Mono	USB
HP LaserJet 1200 Printer	Mono	USB
HP DeskJet 9808d Printer	Color	USB
HP Color LaserJet 2800 All-in-one Printer	Color	USB, Network
HP DeskJet 9800 Printer	Color	USB
HP LaserJet 2200 Series Printer	Mono	USB; Network
HP Color LaserJet 4600dn Printer	Color	USB
HP DeskJet 933c Printer	Color	USB
HP DeskJet 642c Printer	Color	USB
HP DeskJet 6120 Color Inkjet Printer	Color	USB
HP LaserJet 2430t Printer	Mono	USB; Network
HP PhotoSmart 320 Compact Photo Printer	Color	USB
HP DeskJet 450ci Mobile Printer	Color	USB
HP OfficeJet 7205 All-in-one Printer	Color	USB, Network
HP LaserJet 5100tn Printer	Mono	USB
HP DeskJet 5740 Color Inkjet Printer	Color	USB
HP PSC 1504 All-in-one Printer	Color	USB
HP LaserJet 4200dtnsl Printer	Mono	USB; Network

HP LaserJet 1150 Printer	Mono	USB
HP PhotoSmart 3213 All-in-one Printer	Color	USB, Network
HP PSC 2410v PhotoSmart All-in-one Printer	Color	USB
HP Color LaserJet 4600n Printer	Color	USB
HP PhotoSmart 7762 Photo Printer	Color	USB
HP LaserJet 2430n Printer	Mono	USB; Network
HP DeskJet 9680gp Printer	Color	USB
HP LaserJet 3200m All-in-one Printer	Mono	USB
HP PSC 2450 PhotoSmart All-in-one Printer	Color	USB
HP PhotoSmart 470 Series Compact Photo Printer	Color	USB
HP PhotoSmart 7350 Series Printer	Color	USB
HP PhotoSmart 7150 Series Printer	Color	USB
HP LaserJet 4100tn Printer	Mono	USB
HP LaserJet 5000 Printer	Mono	USB; Network
HP LaserJet 2420d Printer	Mono	USB; Network
HP DeskJet 5745 Color Inkjet Printer	Color	USB
HP LaserJet 2300 Printer	Mono	USB; Network
HP Business Inkjet 1200 Printer	Color	USB
HP Business Inkjet 2600 Printer	Color	USB
HP OfficeJet v30 All-in-one Printer	Color	USB
HP PhotoSmart 335v Compact Photo Printer	Color	USB
HP DeskJet 952c Printer	Color	USB
HP PSC 2110xi All-in-one Printer	Color	USB
HP LaserJet 1320n Printer	Mono	USB; Network
HP DeskJet 3818 Color Inkjet Printer	Color	USB
HP PhotoSmart 7760v Photo Printer	Color	USB
HP DeskJet 980c Printer	Color	USB
HP PhotoSmart 7550w Printer	Color	USB
HP PhotoSmart 7350v Printer	Color	USB
HP LaserJet 1220 All-in-one Printer	Mono	USB
HP PhotoSmart 7850v Printer	Color	USB
HP LaserJet 5si Nx Printer	Mono	USB
HP PSC 2300 Series All-in-one Printer	Color	USB, Network
HP DeskJet 1200c/ps Printer	Color	USB
HP PhotoSmart 329 Compact Photo Printer	Color	USB
HP DeskJet 5650v Color Inkjet Printer	Color	USB
HP DeskJet 9650 Printer	Color	USB
HP PhotoSmart 7268 Photo Printer	Color	USB
HP DeskJet 845c Printer	Color	USB
HP PhotoSmart 3308 All-in-one Printer	Color	USB, Network
HP PSC 2405 PhotoSmart All-in-one Printer	Color	USB
HP DeskJet 6122 Color Inkjet Printer	Color	USB, Network
HP LaserJet 8100n Printer	Mono	USB

HP DeskJet 9803 Printer	Color	USB
HP OfficeJet d145 All-in-one Printer	Color	USB, Network
HP PhotoSmart 2575a All-in-one Printer	Color	USB, Network
HP DeskJet 5150v Color Inkjet Printer	Color	USB
HP DeskJet 6540d Color Inkjet Printer	Color	USB
HP PhotoSmart 7760 Photo Printer	Color	USB
HP OfficeJet 5110 All-in-one Printer	Color	USB
HP LaserJet 9000dn Printer	Mono	USB; Network
HP DeskJet 1220c Printer	Color	USB
HP PhotoSmart 2710xi All-in-one Printer	Color	USB, Network
HP Color LaserJet 4500 Printer	Color	USB, Network
HP PhotoSmart 8250 Printer	Color	USB
HP PhotoSmart 325 Compact Photo Printer	Color	USB
HP PhotoSmart 375v Compact Photo Printer	Color	USB
HP Color LaserJet 8550 Printer	Color	USB
HP LaserJet 1160le Printer	Mono	USB
HP OfficeJet 6205 All-in-one Printer	Color	USB
HP PhotoSmart 3313 All-in-one Printer	Color	USB, Network
HP DeskJet 656cvr Printer	Color	USB
HP PSC 950xi All-in-one Printer	Color	USB
HP PhotoSmart 7760w Photo Printer	Color	USB
HP LaserJet 9040 Printer	Mono	USB; Network
HP Color LaserJet 2550l Printer	Color	USB, Network
HP DeskJet 5940 Photo Printer	Color	USB
HP DeskJet 5552 Color Inkjet Printer	Color	USB
HP PhotoSmart 2575 All-in-one Printer	Color	USB, Network
HP Color LaserJet 4650dtn Printer	Color	USB, Network
HP PSC 1600 All-in-one Printer	Color	USB
HP PhotoSmart 7345 Printer	Color	USB
HP DeskJet 975c Printer	Color	USB
HP DeskJet 350cbi Printer	Color	USB
HP PSC 920 All-in-one Printer	Color	USB
HP Color LaserJet 2550n Printer	Color	USB, Network
HP LaserJet 1200n Printer	Mono	USB
HP PhotoSmart 245v Compact Photo Printer	Color	USB
HP Color LaserJet 8550dn Printer	Color	USB
HP Business Inkjet 2600dn Printer	Color	USB
HP DeskJet 3820w Color Inkjet Printer	Color	USB
HP DeskJet 9868 Printer	Color	USB
HP PhotoSmart 335 Compact Photo Printer	Color	USB
HP LaserJet 4200n Printer	Mono	USB; Network
HP Color LaserJet 4600 Series Printer	Color	USB
HP DeskJet 5655 Color Inkjet Printer	Color	USB

HP DeskJet 959c Printer	Color	USB
HP LaserJet 1300 Printer	Mono	USB; Network
HP LaserJet 3200 All-in-one Printer	Mono	USB
HP LaserJet 1200se Printer	Mono	USB
HP LaserJet 4150 Printer	Mono	USB
HP PhotoSmart 7853 Printer	Color	USB
HP DeskJet 1600cm Printer	Color	USB
HP PhotoSmart 1215 Printer	Color	USB
HP LaserJet 2420dn Printer	Mono	USB; Network
HP PSC 2420 PhotoSmart All-in-one Printer	Color	USB
HP DeskJet 6840 Color Inkjet Printer	Color	USB, Network
HP LaserJet 4200 Printer	Mono	USB; Network
HP OfficeJet 7413 All-in-one Printer	Color	USB, Network
HP DeskJet 5420v Photo Printer	Color	USB
HP DeskJet 6540xi Color Inkjet Printer	Color	USB
HP Color LaserJet 5500n Printer	Color	USB
HP LaserJet 2100m Printer	Mono	USB; Network
HP OfficeJet 7135xi All-in-one Printer	Color	USB, Network
HP OfficeJet 6208 All-in-one Printer	Color	USB
HP PhotoSmart 7150w Printer	Color	USB
HP PhotoSmart 8150 Photo Printer	Color	USB
HP PSC 1503 All-in-one Printer	Color	USB
HP Business Inkjet 2800dt Printer	Color	USB, Network
HP PhotoSmart 7450xi Photo Printer	Color	USB
HP DeskJet 990c Printer	Color	USB
HP DeskJet 6520 Color Inkjet Printer	Color	USB
HP PSC 780xi All-in-one Printer	Color	USB
HP OfficeJet 7110xi All-in-one Printer	Color	USB, Network
HP PSC 2410xi PhotoSmart All-in-one Printer	Color	USB
HP OfficeJet v45 All-in-one Printer	Color	USB
HP OfficeJet 5110v All-in-one Printer	Color	USB
HP LaserJet 4100 Printer	Mono	USB
HP PhotoSmart 8049 Printer	Color	USB
HP PhotoSmart 422xi Compact Photo Printer	Color	USB
HP Color LaserJet 4700dn Printer	Color	USB, Network
HP PhotoSmart 335xi Compact Photo Printer	Color	USB
HP DeskJet 935c Printer	Color	USB
HP OfficeJet 9130 All-in-one Printer	Color	USB, Network
HP DeskJet 5160 Color Inkjet Printer	Color	USB
HP LaserJet 5000dn Printer	Mono	USB; Network
HP PhotoSmart 375 Compact Photo Printer	Color	USB
HP Color LaserJet 5550 Printer	Color	USB, Network
HP PSC 2410 PhotoSmart All-in-one Printer	Color	USB

HP PhotoSmart 140 Compact Photo Printer	Color	USB
HP PhotoSmart 8250v Printer	Color	USB
HP LaserJet 2300I Printer	Mono	USB; Network
HP LaserJet 4300 Printer	Mono	USB; Network
HP Color LaserJet 5550dn Printer	Color	USB, Network
HP PhotoSmart 8050xi Printer	Color	USB
HP OfficeJet 6110xi All-in-one Printer	Color	USB
HP DeskJet 940cxi Printer	Color	USB
HP OfficeJet 7310 All-in-one Printer	Color	USB, Network
HP PhotoSmart 375xi Compact Photo Printer	Color	USB
HP Color LaserJet 8550 Multifunction Printer	Color	USB
HP LaserJet 5si Mopier	Mono	USB
HP OfficeJet 6210v All-in-one Printer	Color	USB
HP DeskJet 970c Printer	Color	USB
HP DeskJet 9680 Printer	Color	USB
HP DeskJet 930cm Printer	Color	USB
HP LaserJet 2430tn Printer	Mono	USB; Network
HP DeskJet 825c Printer	Color	USB
HP OfficeJet 6110v All-in-one Printer	Color	USB
HP PhotoSmart p1100xi Printer	Color	USB
HP PhotoSmart 230xi Printer	Color	USB
HP LaserJet 3030 All-in-one Printer	Mono	USB
HP PhotoSmart 148 Compact Photo Printer	Color	USB
HP OfficeJet 6105 All-in-one Printer	Color	USB
HP LaserJet 2200dn Printer	Mono	USB; Network
HP LaserJet 4350tn Printer	Mono	USB; Network